



CRS-311

**1:1 Redundancy Switch
Installation and Operation Manual**
Accessory Product for use only with
Comtech EF Data CDM-Qx/QxL AND SLM-5650/5650A Modems
(Modem Firmware and Hardware Requirements Apply)

Part Number MN/CRS311.IOM
Revision 4

IMPORTANT NOTE: The information contained in this document supersedes all previously published information regarding this product. Product specifications are subject to change without prior notice.



CRS-311

1:1 Redundancy Switch Installation and Operation Manual

Accessory Product for use only with
Comtech EF Data CDM-Qx/QxL and SLM-5650/5650A Modems
(Modem Firmware and Hardware Requirements Apply)

Comtech EF Data is an
AS9100 Rev B / ISO9001:2000
Registered Company



Part Number MN/CRS311.IOM
Revision 4
October 28, 2008

This page is intentionally blank.

Table of Contents

| | |
|---|-------------|
| TABLE OF CONTENTS | III |
| TABLES | VIII |
| FIGURES | IX |
| PREFACE | XI |
| Customer Support | xi |
| About this Manual | xii |
| Related Documents | xii |
| Reporting Comments or Suggestions Concerning this Manual..... | xii |
| Conventions and References | xii |
| Cautions and Warnings | xii |
| Metric Conversion | xii |
| Recommended Standard Designations | xiii |
| Trademarks | xiii |
| Electromagnetic Compatibility (EMC) Compliance | xiii |
| EN55022 - 1997 Compliance..... | xiii |
| EN55024 - 1998 Compliance..... | xiii |
| Federal Communications Commission (FCC)..... | xiii |
| Safety Compliance | xiv |
| EN 60950 | xiv |
| Low Voltage Directive (LVD)..... | xiv |
| Warranty Policy | xv |
| Limitations of Warranty..... | xv |
| Exclusive Remedies | xvi |
| CHAPTER 1. INTRODUCTION | 1-1 |
| 1.1 Overview | 1-1 |
| 1.2 CRS-311 Compatibility | 1-3 |
| 1.3 System-Level Block Diagram | 1-4 |
| 1.4 Description of CRS-311 Features | 1-5 |

| | | |
|-------------------|--|-------------|
| 1.4.1 | Front Panel | 1-5 |
| 1.4.2 | Rear Panel | 1-5 |
| 1.4.3 | CDM-Qx/QxL, SLM-5650/5650A Modem Interface Cards | 1-5 |
| 1.4.3.1 | RMI Cards | 1-6 |
| 1.4.3.2 | TMI Cards | 1-7 |
| 1.4.4 | CRS-311 System Controller and Power Supply Card Assemblies | 1-8 |
| 1.4.5 | CRS-281x IF Switch Module Assemblies | 1-9 |
| 1.4.5.1 | CRS-281x Switch Modules for the CDM-Qx/QxL | 1-9 |
| 1.4.5.2 | CRS-281x Switch Modules for the SLM-5650/5650A | 1-10 |
| 1.4.6 | CRS-351 Overhead Switch Module Assembly | 1-10 |
| 1.5 | Summary of Specifications | 1-11 |
| 1.5.1 | CRS-311 Specifications | 1-11 |
| 1.5.2 | CRS-281x IF Switch Module Specifications | 1-12 |
| 1.6 | Dimensional Envelopes | 1-13 |
| CHAPTER 2. | INSTALLATION | 2-1 |
| 2.1 | Unpacking and Inspection | 2-1 |
| 2.2 | Rack Mounting | 2-1 |
| CHAPTER 3. | CABLES AND CONNECTIONS | 3-1 |
| 3.1 | Overview | 3-1 |
| 3.2 | CDM-Qx/QxL Modem Connections | 3-4 |
| 3.2.1 | RS-485 Connections – CRS-311 to Modems | 3-4 |
| 3.2.2 | Control ‘Y’ Cable Connections – CRS-311 to Modems | 3-4 |
| 3.2.3 | Traffic Data Connections – CRS-311 to Modems | 3-4 |
| 3.2.4 | User Data Connections – CRS-311 to User | 3-5 |
| 3.2.5 | IF Connections – User to CRS-281x Module to Modems | 3-12 |
| 3.3 | SLM-5650/5650A Modem Connections | 3-16 |
| 3.3.1 | Control Cable Connections – CRS-311 to Modems | 3-16 |
| 3.3.2 | Serial Traffic Data Connections – CRS-311 to Modems | 3-16 |
| 3.3.3 | User Data Connections – CRS-311 to User | 3-17 |
| 3.3.4 | Overhead Data Connections – CRS-351 Module to Modems | 3-23 |
| 3.3.5 | IF Connections – User to CRS-281x to Modems | 3-24 |
| CHAPTER 4. | MODEM AND SWITCH CONFIGURATION | 4-1 |
| 4.1 | Modem Configuration | 4-1 |
| 4.1.1 | Modem Power | 4-1 |
| 4.1.2 | Modem Firmware and Hardware Requirements | 4-1 |

| | | |
|-------------------|---|------------|
| 4.1.2.1 | Flash Upgrading..... | 4-2 |
| 4.1.3 | Modem Operational Configuration..... | 4-2 |
| 4.1.4 | Modem Redundancy Configuration..... | 4-2 |
| 4.1.4.1 | Switch to CDM-Qx/QxL Redundancy Configuration | 4-2 |
| 4.1.4.2 | Switch to SLM-5650/5650A Redundancy Configuration | 4-4 |
| 4.2 | Switch Configuration..... | 4-5 |
| 4.2.1 | Switch Power | 4-5 |
| 4.2.2 | Flash Updating..... | 4-5 |
| 4.2.2.1 | Flash Update Help..... | 4-6 |
| 4.2.3 | CRS-311 Front Panel Configuration..... | 4-7 |
| 4.2.3.1 | Set Operation Mode | 4-7 |
| 4.2.3.2 | Set Holdoff Period | 4-8 |
| 4.2.3.2.1 | Set Backup Holdoff Period | 4-8 |
| 4.2.3.2.2 | Set Restore Holdoff Period | 4-9 |
| 4.2.3.3 | Set Alarm Masking | 4-9 |
| CHAPTER 5. | CONNECTOR PINOUTS | 5-1 |
| 5.1 | CRS-230 Controller Connectors..... | 5-1 |
| 5.1.1 | IF Switch Control – DB-25M Connector..... | 5-1 |
| 5.1.2 | 485 Pass-Through – DB-9F Connector..... | 5-2 |
| 5.1.3 | Remote Control – DB-9M Connector..... | 5-2 |
| 5.1.4 | System Alarms – DB-25F Connector | 5-3 |
| 5.2 | TMI User Data Connectors..... | 5-4 |
| 5.2.1 | RS-232/422/V.35 – DB-25F Connector (CRS-316)..... | 5-4 |
| 5.2.2 | Balanced G.703 – DB-15F Connector (CRS-325) | 5-5 |
| 5.2.3 | Unbalanced G.703 – BNC Connectors (CRS-325)..... | 5-6 |
| 5.2.4 | HSSI – HD-50F Connector (CRS-336) | 5-7 |
| 5.2.5 | Gigabit Ethernet (GigE) – RJ-45F Connector (CRS-316/336)..... | 5-8 |
| 5.2.6 | Quad E1 – RJ-48F Connectors (CRS-365)..... | 5-9 |
| 5.2.7 | Gigabit Ethernet (GigE) – (4X) RJ-45F Connectors (CRS-515)..... | 5-10 |
| 5.2.8 | Overhead – DB-25M Connector (CRS-351) | 5-11 |
| CHAPTER 6. | FRONT PANEL OPERATION | 6-1 |
| 6.1 | Introduction..... | 6-1 |
| 6.1.1 | Front Panel LED Indicators | 6-2 |
| 6.1.1.1 | Switch Status LED Indicators..... | 6-2 |
| 6.1.1.2 | Modem Online Status LED Indicators..... | 6-2 |
| 6.1.2 | Front Panel Keypad..... | 6-3 |
| 6.1.3 | Front Panel Vacuum Fluorescent Display (VFD)..... | 6-4 |
| 6.2 | CRS-311 Menu Structure..... | 6-5 |

| | | |
|--------------------|--|-------------|
| 6.3 | Main Select Menu | 6-6 |
| 6.4 | CONFIG (Configuration)..... | 6-7 |
| 6.4.1 | (CONFIG:) MANUAL | 6-8 |
| 6.4.2 | (CONFIG:) AUTO [OFF or ON]..... | 6-8 |
| 6.4.3 | (CONFIG:) HOLDOFFS | 6-8 |
| 6.4.4 | (CONFIG:) MASKS | 6-9 |
| 6.4.4.1 | (CONFIG: MASKS) → MODEM ALARM MASK | 6-9 |
| 6.4.4.2 | (CONFIG: MASKS) → SWITCH ALARM MASK | 6-9 |
| 6.4.4.3 | (CONFIG: MASKS) → AUDIO MASK | 6-10 |
| 6.4.5 | (CONFIG:) REMOTE | 6-10 |
| 6.4.5.1 | (CONFIG: REMOTE) → LOCAL | 6-10 |
| 6.4.5.2 | (CONFIG: REMOTE) → REMOTE | 6-10 |
| 6.4.5.2.1 | (CONFIG: REMOTE → REMOTE) BAUDRATE | 6-10 |
| 6.4.5.2.2 | (CONFIG: REMOTE → REMOTE) INTERFACE | 6-11 |
| 6.4.5.2.3 | (CONFIG: REMOTE → REMOTE) FORMAT | 6-11 |
| 6.5 | INFO (INFORMATION) | 6-11 |
| 6.5.1 | (INFO:) S/N | 6-12 |
| 6.5.2 | (INFO:) ID | 6-12 |
| 6.5.3 | (INFO:) SETUP | 6-12 |
| 6.5.4 | (INFO) IF-SWITCH | 6-12 |
| 6.5.5 | (INFO:) REMCONT (Remote Control Info) | 6-12 |
| 6.5.6 | (INFO:) MASK (Alarms Masked Info) | 6-13 |
| 6.6 | MONITOR..... | 6-13 |
| 6.6.1 | (MONITOR:) STATUS | 6-13 |
| 6.6.2 | (MONITOR:) SW-ALARM | 6-13 |
| 6.6.3 | (MONITOR:) STORED EVENTS | 6-15 |
| 6.6.3.1 | (MONITOR: STORED-EVENTS) → VIEW | 6-16 |
| 6.6.4 | (MONITOR:) COMMS (Communications State) | 6-16 |
| 6.6.5 | (MONITOR:) IO | 6-16 |
| 6.7 | STORE/LD (Store or Load Configuration)..... | 6-17 |
| 6.7.1 | (STORE/LD) STORE | 6-17 |
| 6.7.2 | (STORE/LD) LOAD | 6-18 |
| 6.8 | UTILITY..... | 6-18 |
| 6.8.1 | (UTILITY:) SET-RTC (Set Real-Time Clock) | 6-18 |
| 6.8.2 | (UTILITY:) DISPLAY (Display Brightness) | 6-19 |
| 6.8.3 | (UTILITY:) SW-ID (Switch ID) | 6-19 |
| 6.8.4 | (UTILITY:) INDEP-MODE (Independent Mode) | 6-19 |
| APPENDIX A. | CABLE DRAWINGS..... | A-1 |
| A.1 | Introduction..... | A-1 |

| | | |
|--------------------|---|-------------|
| A.2 | User / Utility Cables | A-1 |
| A.2.1 | RS-530 to RS-422 Data Cable | A-2 |
| A.2.2 | RS-530 to V.35 Data Cable | A-3 |
| A.2.3 | Switch Programming Cable | A-4 |
| A.3 | Control Cables | A-5 |
| A.3.1 | Optional RS-485 Multi-drop Ribbon Cable, (6X) DB-9 Female | A-6 |
| A.3.2 | Standard RS-485 Multi-drop Shielded Cable, (6X) DB-9 Female | A-7 |
| A.3.3 | RS-485 Cable Termination, (15X) DB-9 Male..... | A-8 |
| A.3.4 | RS-485 Null Modem Cable, DB-9 Male | A-9 |
| A.3.5 | Control ‘Y’ Cable for CDM-Qx and CDM-QxL with CnC® | A-10 |
| A.3.6 | Control Cable for SLM-5650/5650A..... | A-11 |
| A.3.7 | Control ‘Y’ Overhead Cable for CRS-351 → SLM-5650/5650A..... | A-12 |
| A.3.8 | Control ‘Y’ Cable for SLM-5650/5650A to CRS-311 | A-13 |
| A.4 | Data Cables | A-14 |
| A.4.1 | RS-232/422, EIA-530 Control and Data Cable, DB-25 | A-15 |
| A.4.2 | Balanced G.703 Data Cable, DB-15 | A-16 |
| A.4.3 | Balanced G.703 / IF Cable, BNC, 75Ω | A-17 |
| A.4.4 | HSSI Data Cable | A-18 |
| A.4.5 | Quad E1 Data Cable for CDM-Qx/QxL | A-19 |
| A.4.6 | Quad E1 / Gigabit Ethernet Connector Cable..... | A-20 |
| A.4.7 | IF Cable, BNC, 50Ω | A-21 |
| A.4.8 | IF Cable, Type ‘N’, 50Ω..... | A-22 |
| A.4.9 | IF Cable, TNC, 50Ω..... | A-23 |
| APPENDIX B. | ADDRESSING SCHEME INFORMATION | B-1 |
| B.1 | Introduction to Addressing | B-1 |
| B.2 | Switch Address | B-2 |
| B.3 | Modem and Transceiver Addresses | B-2 |
| B.3.1 | Setting Up Modems (CDM-Qx/QxL only)..... | B-6 |
| B.4 | M&C Application | B-6 |
| APPENDIX C. | REMOTE CONTROL | C-1 |
| C.1 | Introduction | C-1 |
| C.2 | RS-485 | C-1 |
| C.3 | RS-232 | C-2 |
| C.4 | Basic Protocol | C-2 |
| C.4.1 | Rules for Remote Serial Communications with the CRS-311 | C-2 |

| | | |
|--|--|------------|
| C.5 | Packet Structure..... | C-3 |
| C.5.1 | Start of Packet..... | C-3 |
| C.5.2 | Target Address..... | C-4 |
| C.6 | Instruction Code..... | C-4 |
| C.6.1 | Instruction Code Qualifier | C-4 |
| C.6.2 | Optional Message Arguments..... | C-5 |
| C.6.3 | End of Packet..... | C-6 |
| C.7 | Remote Commands and Queries..... | C-6 |
| APPENDIX D. INDEPENDENT MODE OPERATION | | D-1 |
| D.1 | Introduction..... | D-1 |
| D.2 | Feature Description | D-1 |
| APPENDIX E. CRS-311 RETROFIT FOR SLM-5650/5650A NP INTERFACE OPERATION... | | E-1 |
| E.1 | Introduction..... | E-1 |
| E.1.1 | Field Upgrade Kit KT-0000078 (Required for Retrofit) | E-1 |
| E.1.2 | Retrofit Procedure..... | E-2 |

Tables

| | | |
|-------------|---|------|
| Table 1-1. | CRS-311 Switch/Modem Compatibility | 1-3 |
| Table 5-1. | 485 Pass-Through User Data Connector | 5-2 |
| Table 5-2. | Remote Control User Data Connector..... | 5-2 |
| Table 5-3. | System Alarms User Data Connector..... | 5-3 |
| Table 5-4. | EIA-422/530 / V.35 / Sync EIA-232 User Data Connector | 5-4 |
| Table 5-5. | Balanced G.703 User Data Connector..... | 5-5 |
| Table 5-6. | Unbalanced G.703 User Data Connectors..... | 5-6 |
| Table 5-7. | HSSI User Data Connector..... | 5-7 |
| Table 5-8. | GigE Connector | 5-8 |
| Table 5-9. | Quad E1 Connector (Typical Ports 1 through 4)..... | 5-9 |
| Table 5-10. | GigE Connector (Typical Port 1 through Port 4) | 5-10 |
| Table 5-11. | Overhead User Data Connector..... | 5-11 |

Figures

| | |
|---|------|
| Figure 1-1. CRS-311 1:1 Redundancy Switch..... | 1-1 |
| Figure 1-2. System-Level Block Diagram..... | 1-4 |
| Figure 1-3. CRS-311 Front Panel..... | 1-5 |
| Figure 1-4. CRS-311 Rear Panel Configuration Example..... | 1-5 |
| Figure 1-5. CRS-305 RMI (PL/11494-1)..... | 1-6 |
| Figure 1-6. CRS-306 RMI (PL/11494-2)..... | 1-6 |
| Figure 1-7. CRS-307 RMI (PL/11494-3)..... | 1-6 |
| Figure 1-8. CRS-505 RMI (PL-0000293)..... | 1-6 |
| Figure 1-9. CRS-316 TMI RS422 / GigE (PL/12498-1)..... | 1-7 |
| Figure 1-10. CRS-325 TMI G.703 (PL/11492-1)..... | 1-7 |
| Figure 1-11. CRS-336 TMI HSSI / GigE (PL/12499-1)..... | 1-7 |
| Figure 1-12. CRS-365 TMI..... | 1-7 |
| Figure 1-13. CRS-515 TMI..... | 1-7 |
| Figure 1-14. CRS-230 System Controller (AS/0377)..... | 1-8 |
| Figure 1-15. CRS-241 AC Power Supply (PL/12067-1)..... | 1-8 |
| Figure 1-16. CRS-251 DC Power Supply (PL-0000157)..... | 1-8 |
| Figure 1-17. CRS-281 IF Switch Module: 70/140 MHz Type ‘BNC’ (PL/12040-3 [75Ω] or PL/12040-4 [50Ω])..... | 1-9 |
| Figure 1-18. CRS-281A IF Switch Module: L-Band Type ‘N’ 50Ω (PL/13017-1)..... | 1-9 |
| Figure 1-19. CRS-281 IF Switch Module: Type ‘TNC’ 50Ω (PL/12040-2)..... | 1-10 |
| Figure 1-20. CRS-281L IF Switch Module:..... | 1-10 |
| Figure 1-21. CRS-351 Overhead Switch Module (PL/13154-1)..... | 1-10 |
| Figure 1-22. CRS-311 Dimensional Envelope..... | 1-13 |
| Figure 2-1. Typical Rack-mounted Configuration..... | 2-2 |
| Figure 3-1. CDM-Qx/QxL Cabling Example – RS-485 Multi-drop Cable..... | 3-6 |
| Figure 3-2. CDM-Qx/QxL Control ‘Y’ and EIA-530/RS-232 Traffic Data Cables..... | 3-7 |
| Figure 3-3. CDM-Qx/QxL Control ‘Y’ and Balanced G.703 Traffic Data Cables..... | 3-8 |
| Figure 3-4. CDM-Qx/QxL Control ‘Y’ and Unbalanced G.703 Traffic Data Cables..... | 3-9 |
| Figure 3-5. CDM-Qx/QxL Control and HSSI Traffic Data Cables..... | 3-10 |
| Figure 3-6. CDM-Qx/QxL Control and Quad E1 Traffic Data Cables..... | 3-11 |
| Figure 3-7. CDM-Qx IF Cabling Example – CRS-281 (70/140 MHz, 50Ω or 75Ω BNC)..... | 3-13 |
| Figure 3-8. CDM-QxL IF Cabling Example – CRS-281A (L-Band)..... | 3-14 |
| Figure 3-9. SLM-5650/5650A Control and HSSI, Ethernet Traffic (Single Port Bridge Mode) Data Cables..... | 3-18 |
| Figure 3-10. SLM-5650/5650A Control and G.703 Traffic Data Cables..... | 3-19 |
| Figure 3-11. SLM-5650/5650A Control and EIA-530 Traffic Data Cables..... | 3-20 |
| Figure 3-12. SLM-5650/5650A Control and Ethernet Traffic (Multi-Port Bridge Mode) Data Cables..... | 3-21 |
| Figure 3-13. SLM-5650/5650A Control and Ethernet Traffic (Multi-Port Router Mode) Data Cables..... | 3-22 |
| Figure 3-14. SLM-5650/5650A Overhead Data Cables..... | 3-23 |
| Figure 3-15. SLM-5650/5650A IF Cabling Example – CRS-281 (70/140 MHz)..... | 3-25 |
| Figure 3-16. SLM-5650/5650A IF Cabling Example – CRS-281L (L-Band)..... | 3-26 |

| | |
|---|------|
| Figure 3-17. SLM-5650/5650A Mixed IF Band Cabling Example – CRS-281 ‘TNC’ (70/140 MHz Tx, L-Band Rx)..... | 3–27 |
| Figure 3-18. SLM-5650/5650A Mixed IF Band Cabling Example – CRS-281L (70/140 MHz Tx, L-Band Rx)..... | 3–28 |
| Figure 4-1. CDM-Qx/QxL Serial Communication Configuration | 4–2 |
| Figure 4-2. CDM-Qx/QxL / CRS-311 RS-485 Scheme | 4–3 |
| Figure 4-3. Flash Update via Internet | 4–6 |
| Figure 6-1. CRS-311 Front Panel | 6–1 |
| Figure 6-2. CRS-311 Menu Tree | 6–5 |
| Figure A-1. DCE Conversion Cable: RS-530 to RS-422/449 | A-2 |
| Figure A-2. DCE Conversion Cable: RS-530 to V.35 | A-3 |
| Figure A-3. Switch Programming Cable | A-4 |
| Figure A-4. Optional RS-485 Multi-Drop Ribbon Cable (CA-0000095)..... | A-6 |
| Figure A-5. Standard RS-485 Multi-Drop Shielded Cable (CA-0000096)..... | A-7 |
| Figure A-6. RS-485 Cable Termination (CA/WR11418-1) | A-8 |
| Figure A-7. RS-485 Null Modem Cable (CA/WR11419-1)..... | A-9 |
| Figure A-8. Control ‘Y’ Cable for CDM-QxL with CnC [®] (CA-0000009)..... | A-10 |
| Figure A-9. SLM-5650/5650A Control Cable (CA/WR12136-2)..... | A-11 |
| Figure A-10. SLM-5650/5650A Control ‘Y’ Overhead Cable (CA-0000006)..... | A-12 |
| Figure A-11. SLM-5650/5650A Control ‘Y’ Cable (CA/WR12842-4)..... | A-13 |
| Figure A-12. RS-232/422, EIA-530 Control and Data Cable (CA/WR0066-4)..... | A-15 |
| Figure A-13. Balanced G.703 Data Cable (CA/WR9038-4)..... | A-16 |
| Figure A-14. Balanced G.703 / IF Cable, BNC 75Ω (PL/0813-4)..... | A-17 |
| Figure A-15. HSSI Data Cable (CA/WR9189-4)..... | A-18 |
| Figure A-16. CDM-Qx/QxL Quad E1 Data Cable (CA/WR13018-2)..... | A-19 |
| Figure A-17. Quad E1 / GigE Connector Cable (PP/CAT5FF3FTGY)..... | A-20 |
| Figure A-18. IF Cable, BNC 50Ω for CRS-281 (70/140 MHz) IF Switch (PL/0946-1)..... | A-21 |
| Figure A-19. IF Cable, Type ‘N’ 50Ω for CRS-281A / CRS-281L (L-Band) IF Switches (CA/RF10453-4)..... | A-22 |
| Figure A-20. IF Cable, TNC 50Ω for CRS-281 (70/140 MHz) IF Switch (CA/3005-1)..... | A-23 |
| Figure B-1. CRS-311 Addressing Scheme Example: External RS-232 with SLM-5650/5650A Modems..... | B–3 |
| Figure B-2. CRS-311 Addressing Scheme Example: External RS-485 with SLM-5650/5650A Modems..... | B–3 |
| Figure B-3. CRS-311 Addressing Scheme Example: External RS-232 with CDM-Qx/QxL Modems..... | B–4 |
| Figure B-4. CRS-311 Addressing Scheme Example: External RS-485 with CDM-Qx/QxL Modems..... | B–4 |
| Figure B-5. CRS-311 Addressing Scheme Example: External RS-485 with CDM-Qx/QxL Modems, EDMAC CRS-311 to CRS-311 | B–5 |
| Figure D-1. Standard Connections to CRS-311..... | D–2 |
| Figure D-2. CRS-311 in Independent Mode..... | D–2 |

PREFACE

Customer Support

Contact the Comtech EF Data Customer Support Department for:

- Product support or training
- Reporting comments or suggestions concerning manuals
- Information on upgrading or returning a product

A Customer Support representative may be reached at:

Comtech EF Data
Attention: Customer Support Department
2114 West 7th Street
Tempe, Arizona 85281 USA
480.333.2200 (Main Comtech EF Data number)
480.333.4357 (Customer Support Desk)
480.333.2161 FAX

To return a Comtech EF Data product (in-warranty and out-of-warranty) for repair or replacement:

- **Contact** the Comtech EF Data Customer Support Department. Be prepared to supply the Customer Support representative with the model number, serial number, and a description of the problem.
- **Request** a Return Material Authorization (RMA) number from the Comtech EF Data Customer Support representative.
- **Pack** the product in its original shipping carton/packaging to ensure that the product is not damaged during shipping.
- **Ship** the product back to Comtech EF Data. (Shipping charges should be prepaid.)

For Online Customer Support:

An RMA number request can be requested electronically by contacting the Customer Support Department through the online support page at www.comtechefdata.com/support.asp:

- **Click** on “**Service**” for detailed instructions on our return procedures.
- **Click** on the “**RMA Request Form**” hyperlink, then fill out the form completely before sending.
- **Send e-mail** to the Customer Support Department at service@comtechefdata.com.

For information regarding this product’s warranty policy, refer to the Warranty Policy, p. xv.

About this Manual

This manual provides installation and operation information for the Comtech EF Data CRS-311 1:1 Redundancy Switch. This is a technical document intended for earth station engineers, technicians, and operators responsible for the operation and maintenance of the CRS-311.

Related Documents

- *Comtech EF Data CDM-Qx Multi-Channel Satellite Modem Installation and Operation Manual*
- *Comtech EF Data SLM-5650 Satellite Modem Installation and Operation Manual*
- *Comtech EF Data SLM-5650A Satellite Modem Installation and Operation Manual*

Reporting Comments or Suggestions Concerning this Manual

Comments and suggestions regarding the content and design of this manual are appreciated. To submit comments, please contact the Comtech EF Data Technical Publications department: TechnicalPublications@comtechefdata.com

Conventions and References

Cautions and Warnings



IMPORTANT or **NOTE** indicates a statement that is associated with the task being performed or information critical for proper equipment function.



CAUTION indicates a hazardous situation that, if not avoided, may result in minor or moderate injury. **CAUTION** may also be used to indicate other unsafe practices or risks of property damage.



WARNING indicates a potentially hazardous situation that, if not avoided, could result in death or serious injury.

Metric Conversion

Metric conversion information is located on the inside back cover of this manual. This information is provided to assist the operator in cross-referencing non-Metric to Metric conversions.

Recommended Standard Designations

Recommended Standard (RS) Designations are interchangeable with the designation of the Electronic Industries Association (EIA).

Trademarks

Windows is a trademark of the Microsoft Corporation.

Other product names mentioned in this manual may be trademarks or registered trademarks of their respective companies and are hereby acknowledged.

Electromagnetic Compatibility (EMC) Compliance

This is a Class A product. In a domestic environment, it may cause radio interference that requires the user to take adequate protection measures.

EN55022 - 1997 Compliance

This equipment meets the radio disturbance characteristic specifications for information technology equipment as defined in EN55022.

EN55024 - 1998 Compliance

This equipment meets the EMC/immunity characteristics for the limits and methods of measurement for information technology equipment per EN55024-1998.

Federal Communications Commission (FCC)

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment.

This equipment generates, uses, and can radiate radio frequency energy. If not installed and used in accordance with the instruction manual, it may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference; in which case, users are required to correct the interference at their own expense.



To ensure compliance, properly shielded cables for DATA I/O shall be used. More specifically, these cables shall be shielded from end to end, ensuring a continuous shield.

Safety Compliance

EN 60950


Applicable testing is routinely performed as a condition of manufacturing on all units to ensure compliance with safety requirements of EN60950. This equipment meets the Safety of Information Technology Equipment specification as defined in EN60950.

Low Voltage Directive (LVD)

The following information is applicable for the European Low Voltage Directive (EN60950):

| | |
|---|---|
| <HAR> | Type of power cord required for use in the European Community. |
|  | CAUTION: Double-pole/Neutral Fusing ACHTUNG: Zweipolige bzw. Neutralleiter-Sicherung |

International Symbols:

| Symbol | Definition |
|---|---------------------|
| ~ | Alternating Current |
|  | Fuse |

| Symbol | Definition |
|---|----------------------------------|
|  | Protective Earth / Safety Ground |
|  | Chassis Ground |



For additional symbols, refer to Cautions and Warnings listed earlier in this Preface.

Warranty Policy

Comtech EF Data products are warranted against defects in material and workmanship for a period of two years from the date of shipment. During the warranty period, Comtech EF Data will, at its option, repair or replace products that prove to be defective.

For equipment under warranty, the owner is responsible for freight to Comtech EF Data and all related customs, taxes, tariffs, insurance, etc. Comtech EF Data is responsible for the freight charges only for return of the equipment from the factory to the owner. Comtech EF Data will return the equipment by the same method (i.e., Air, Express, Surface) as the equipment was sent to Comtech EF Data.

All equipment returned for warranty repair must have a valid RMA number issued prior to return and be marked clearly on the return packaging. Comtech EF Data strongly recommends all equipment be returned in its original packaging.

Comtech EF Data Corporation's obligations under this warranty are limited to repair or replacement of failed parts, and the return shipment to the buyer of the repaired or replaced parts.

Limitations of Warranty

The warranty does not apply to any part of a product that has been installed, altered, repaired, or misused in any way that, in the opinion of Comtech EF Data Corporation, would affect the reliability or detracts from the performance of any part of the product, or is damaged as the result of use in a way or with equipment that had not been previously approved by Comtech EF Data Corporation.

The warranty does not apply to any product or parts thereof where the serial number or the serial number of any of its parts has been altered, defaced, or removed.

The warranty does not cover damage or loss incurred in transportation of the product.

The warranty does not cover replacement or repair necessitated by loss or damage from any cause beyond the control of Comtech EF Data Corporation, such as lightning or other natural and weather related events or wartime environments.

The warranty does not cover any labor involved in the removal and or reinstallation of warranted equipment or parts on site, or any labor required to diagnose the necessity for repair or replacement.

The warranty excludes any responsibility by Comtech EF Data Corporation for incidental or consequential damages arising from the use of the equipment or products, or for any inability to use them either separate from or in combination with any other equipment or products.

A fixed charge established for each product will be imposed for all equipment returned for warranty repair where Comtech EF Data Corporation cannot identify the cause of the reported failure.

Exclusive Remedies

Comtech EF Data Corporation's warranty, as stated is in lieu of all other warranties, expressed, implied, or statutory, including those of merchantability and fitness for a particular purpose. The buyer shall pass on to any purchaser, lessee, or other user of Comtech EF Data Corporation's products, the aforementioned warranty, and shall indemnify and hold harmless Comtech EF Data Corporation from any claims or liability of such purchaser, lessee, or user based upon allegations that the buyer, its agents, or employees have made additional warranties or representations as to product preference or use.

The remedies provided herein are the buyer's sole and exclusive remedies. Comtech EF Data shall not be liable for any direct, indirect, special, incidental, or consequential damages, whether based on contract, tort, or any other legal theory.

Chapter 1. INTRODUCTION

1.1 Overview



The CRS-311 is an accessory product designed specifically for the Comtech EF Data CDM-Qx/QxL or SLM-5650/5650A modems, and must not be used with any other equipment.



Figure 1-1. CRS-311 1:1 Redundancy Switch

The CRS-311 1:1 Redundancy Switch – shown here in and referred to throughout this manual as “the Switch” – is a companion product for use with the Comtech EF Data CDM-Qx/QxL or SLM-5650/5650A Satellite Modems. Designed to continuously monitor a pair of modems in a redundant configuration, the CRS-311 automatically switches data and IF signals from a failed Traffic Modem to the Redundant Modem in the event of an equipment failure or undesired traffic condition. Traffic paths are fully protected, and the system operator can have increased confidence that equipment failures will not adversely affect system availability.

Accordingly, a 1:1 system comprises a Traffic Modem, a Redundant Modem, and the CRS-311 1:1 Redundancy Switch.



For the CRS-311 to operate correctly, the Traffic Modem and the Redundant Modem must be of the same model and firmware revision. Permitted firmware revisions are discussed in Chapter 4. MODEM AND SWITCH CONFIGURATION.

A key feature of the CRS-311 architecture is its ability to allow the Redundant Modem to ‘bridge’ the Traffic Modem. The Switch automatically configures the Redundant Modem to match the configuration of the Traffic Modem. The Switch also copies the Traffic Modem’s terrestrial transmit clock/data and routes it to the Redundant Modem, along with the Traffic’s Modem’s Rx IF (via use of the CRS-281x IF Switch Module) – see **Sect. 1.4.5 CRS-311 IF Switch Module Assemblies** in this chapter. Because of this, no external test equipment is needed to determine the health of the Redundant Modem – live traffic is used at all times to verify performance.

Construction Features: The CRS-311 is modular in construction. All replaceable modules insert into slots in the back panel. This includes the controller, Traffic Modem Interface (TMI), Redundant Modem Interface (RMI), Overhead Module, IF Modules, and Power Supply Units (PSUs).

Because power consumption is below 25 watts for a fully populated Switch, no fan cooling is required.

Key Reliability Features: The CRS-311 incorporates the following key reliability features:

- Twin, independent, AC or DC power supplies
- Primary traffic paths are maintained, error-free, when power is removed.
- The TMI can be completely removed from the CRS-311, with cables still attached, and traffic is not interrupted or affected.

Ease of Connection: Connection to the Traffic and Redundant Modems is remarkably simple. One cable connected to the HD-15 port on the TMI or RMI carries the Switch-to-Modem communications, fault indications and remote control.

For the CDM-Qx/QxL: These modems require an additional RS-485 multi-drop cable from the Switch to all modems to provide remote control interface capability.

For RS-232/485 M&C User connections: A direct user-to-modem serial RS-232/485 communication connection is not permissible when connected to the CRS-311. The user must instead connect to the DB-9 "Remote" connector on the CRS-230 System Controller (installed on the CRS-311). For detailed information on remote addressing schemes, refer to **Appendix B. ADDRESSING SCHEME INFORMATION.**

TMI Monitoring: Terrestrial user clock and data signals to and from a Traffic Modem are routed through the TMI via a set of relays. This is arranged so that the de-energized (unpowered) state connects the data signals directly through to the Traffic Modem. If the power supplies to the system are lost, or if the TMI carrying traffic is removed, no interruption of the traffic will take place. It should also be noted that, in normal circumstances where the Redundant Modem is not in service, no data is carried through the CRS-311 backplane - all data is routed via the TMI.

Interfaces: The CRS-311 supports all of the interface types available on the CDM-Qx/QxL or the SLM-5650/5650A modems via the following TMIs:

- EIA-530 or Ethernet (via Ethernet Bridge Mode) – CRS-316
- G.703 (Balanced or Unbalanced) – CRS-325
- HSSI or Ethernet (via Ethernet Bridge Mode) – CRS-336
- Quad E1 – CRS-365
- 4-Port Ethernet (via Ethernet Bridge Mode or Router Mode) – CRS-515

Refer to **Sect. 1.4.3.2 TMI Cards** and **Sect. 1.5.1 CRS-311 Specifications** for more information on these interface modules and their specifications.

CRS-281x Selection: The CRS-281x switch module connects the online modulator's Tx IF signal to the RF up-converter. It also passively splits the Rx IF signal to provide both demodulators with the same IF signal coming from the LNB, thus reducing switching time.

Three CRS-281x switch modules are compatible for use with the CDM-Qx/QxL modem:

- The CRS-281 (70/140 MHz IF) with Type 'BNC' (50Ω) connectors;
- The CRS-281 (70/140 MHz IF) with Type 'BNC' (75Ω) connectors;
- The CRS-281L (L-Band IF) with Type 'N' (50Ω) connectors.

Two CRS-281x switch modules are compatible for use with the SLM-5650/5650A modem:

- The CRS-281 (70/140 MHz IF) with Type ‘TNC’ (50Ω) connectors;
- The CRS-281L (L-Band IF) with Type ‘N’ (50Ω) connectors.



The SLM-5650/5650A modem permits simultaneous operation of the Tx IF and Rx IF bands at 70/140 MHz and L-Band frequencies, independent of one another. If the user wants the Tx and Rx to be of different IF bands, the CRS-281x module must be selected based on the Tx IF band. An external splitter is then used for the Rx IF band when that side differs from the Tx IF band – refer to Figure 3-17 and Figure 3-18 in Sect. 3.3.5 IF Connections – User to CRS-281x to Modems for configuration examples.

Refer to **Sect. 1.4.5 CRS-281x IF Switch Module Assemblies** for more information on these switch modules and their use.

CRS-351 Option: Where protection of the overhead signals (backward alarms, audio ESC, data ESC, etc.) is desired, the CRS-351 Overhead Module may be added.

1.2 CRS-311 Compatibility

Table 1-1 shows the Comtech EF Data modems that are compatible for use with the CRS-311 1:1 Redundancy Switch:

Table 1-1. CRS-311 Switch/Modem Compatibility

| Modem | Optional Switch Modules |
|----------------|--|
| CDM-Qx | CRS-281 IF Switch Module (70/140 MHz) - 50Ω or 75Ω BNC  Up to one modulator and one demodulator allowed per CDM-Qx/QxL. |
| CDM-QxL | CRS-281A IF Switch Module (L-Band)  Up to one modulator and one demodulator allowed per CDM-Qx/QxL. |
| SLM-5650/5650A | CRS-281 IF Switch Module (70/140 MHz) - 50Ω TNC CRS-281L IF Switch Module (L-Band) CRS-351 ESC Switch Module (IDR Overhead) |

Compatibility Note: The CiM-25, Comtech EF Data’s low-cost Internet Protocol (IP) Monitor & Control (M&C) interface for existing CEFD modems, is not compatible for use on modems operating within a CRS-311 1:1 redundancy system. Taking this prohibition of use under further consideration, the CiM-25 should **not**, *under any circumstances*, be connected to the Remote port on the CRS-311’s CRS-230 Controller card for control of the Switch and modems.

1.3 System-Level Block Diagram

Figure 1-2 shows the system-level block diagram of the CRS-311 1:1 Redundancy Switch, including the CRS-281 IF Switch.




Figure 1-2. System-Level Block Diagram

1.4 Description of CRS-311 Features

1.4.1 Front Panel

Figure 1-3 shows the CRS-311 front panel. The CRS-311 is constructed as a 2RU-high, rack-mounting chassis that can be freestanding if desired. It is provided with rack handles at the front for easy removal from and placement into a rack.



Figure 1-3. CRS-311 Front Panel

1.4.2 Rear Panel

Figure 1-4 shows the back panel of a typical CRS-311 chassis configuration.




Figure 1-4. CRS-311 Rear Panel Configuration Example

1.4.3 CDM-Qx/QxL, SLM-5650/5650A Modem Interface Cards


The following tables indicate which TMI (Traffic Modem Interface) and which RMI (Redundant Modem Interface) should be used with each modem and data type:

| CDM-Qx/QxL Modem | | |
|-----------------------------|----------|----------|
| Data Type | TMI Type | RMI Type |
| EIA-530/422/V.35, EIA-232 | CRS-316 | CRS-305 |
| G.703 T1/E1 Bal D&I , Unbal | CRS-325 | |
| HSSI | CRS-336 | |
| Quad E1 | CRS-365 | |

| SLM-5650/5650A Modem | | |
|--------------------------------------|----------|-----------------------|
| Data Type | TMI Type | RMI Type (See note 3) |
| MIL-STD-188-114, EIA-530/422 or GigE | CRS-316 | CRS-307 |
| G.703 Bal/UnBal | CRS-325 | CRS-306 |
| HSSI or GigE | CRS-336 | CRS-306/307 |
| 4-Port Ethernet | CRS-515 | CRS-505 |

1.4.3.1 RMI Cards


Figure 1-5.
CRS-305 RMI
(PL/11494-1)



HD-50 Female

HD-15 Female

Figure 1-6.
CRS-306 RMI
(PL/11494-2)




HD-50 Female

HD-15 Female

DB-25 Male

DB-15 Male

Figure 1-7.
CRS-307 RMI
(PL/11494-3)



HD-50 Female

10/100/1000


HD-15 Female

DB-25 Male

(4X) RJ-45

HD-15 Female

Figure 1-8.
CRS-505 RMI
(PL-0000293)



HD-50 Female

DB-9 Male

1.4.3.2 TMI Cards

Figure 1-9.
CRS-316 TMI
RS422 / GigE
(PL/12498-1)




Figure 1-10.
CRS-325 TMI
G.703
(PL/11492-1)




Figure 1-11.
CRS-336 TMI
HSSI / GigE
(PL/12499-1)




Figure 1-12.
CRS-365 TMI
Quad E1 (1-4 ports)
(PL/12985-1)





Figure 1-13.
CRS-515 TMI
4-Port Ethernet
(PL-0000294)



1.4.4 CRS-311 System Controller and Power Supply Card Assemblies

Figure 1-14.
CRS-230
System Controller
(AS/0377)




Figure 1-15.
CRS-241
AC Power Supply
(PL/12067-1)




Figure 1-16.
CRS-251
DC Power Supply
(PL-0000157)



1.4.5 CRS-281x IF Switch Module Assemblies

The CRS-281/281x are the IF Switch Module Assemblies for the CRS-311. Each module connects the Tx IF signal on the up-converter to the appropriate online modulator, and passively splits the Rx IF signal to provide both demodulators with the same IF signal from the LNB, thus reducing switching time.

Additionally, the CRS-281A switch module switches all of the BUC and LNB interface signals that are multiplexed onto the Tx and Rx coaxial cables:

- Tx and Rx L-Band signals
- 10 MHz reference to BUC and LNB
- DC Power to BUC and LNB
- FSK signaling to the BUC.

1.4.5.1 CRS-281x Switch Modules for the CDM-Qx/QxL

- CRS-281 (70/140 MHz IF) with Type 'BNC' (75Ω or 50Ω) connectors (**Figure 1-17**);
- CRS-281A (L-Band IF) with Type 'N' (50Ω) connectors (**Figure 1-18**).




Figure 1-17. CRS-281 IF Switch Module:
70/140 MHz Type 'BNC' (PL/12040-3 [75Ω]
or PL/12040-4 [50Ω])




Figure 1-18. CRS-281A IF Switch Module:
L-Band Type 'N' 50Ω (PL/13017-1)

1.4.5.2 CRS-281x Switch Modules for the SLM-5650/5650A

- The CRS-281 (70/140 MHz IF) with Type ‘TNC’ (50Ω) connectors (**Figure 1-19**);
- The CRS-281L (L-Band IF) with Type ‘N’ connectors (**Figure 1-20**).




Figure 1-19. CRS-281 IF Switch Module:
Type ‘TNC’ 50Ω (PL/12040-2)





Figure 1-20. CRS-281L IF Switch Module:
L-Band Type ‘N’ 50Ω (PL/12040-1)

1.4.6 CRS-351 Overhead Switch Module Assembly

As explained in detail in the pertinent modem sections of **CHAPTER 3. CABLES AND CONNECTIONS**, the User’s equipment should be connected directly to the P1 User Interface port on the CRS-351 Overhead Switch Module (**Figure 1-21**) instead of connecting directly to the SLM-5650/5650A traffic modem’s P1 Overhead Data port.

Figure 1-21.
CRS-351
Overhead
Switch Module
(PL/13154-1)



DB-50 Female

1.5 Summary of Specifications

1.5.1 CRS-311 Specifications

| Characteristic | Requirement | | |
|--|--|----------------------|---------------------------|
| Switch Type | <ul style="list-style-type: none"> • 1:1 Redundancy Switch system • Bridging architecture • C161 control processor | | |
| Compatible Modems | <ul style="list-style-type: none"> • SLM-5650/5650A • CDM-Qx/QxL | | |
| Operating Modes | <ul style="list-style-type: none"> • Fully automatic or manual • Force Traffic Modem to Redundant Modem • Programmable holdoff-to-backup and holdoff-to-restore times (from 1 to 99 seconds) | | |
| Switching Conditions | Switch to Redundant Modem following a Unit fault, Tx traffic fault, or Rx traffic fault | | |
| Switching Time | 6 seconds max. (Delay interval set to minimum, 1 sec) | | |
| IF Switching | CRS-311 with CRS-281 IF Module: all modems outputs ON all the time. | | |
| Temperature | <ul style="list-style-type: none"> • 0 to +50°C (32 to 122°F) Operating • 50 to 100°C (122 to 212°F) Storage | | |
| Humidity | 95% at +50°C (122°F), Non-condensing | | |
| Environmental | Operating temperature range 0° to 50°C (32° to 122°F) | | |
| Redundant Modem Signal Source | The traffic paths (bridge mode) (both Rx IF and Tx data) | | |
| Front Panel | <ul style="list-style-type: none"> • Vacuum Fluorescent Display (VFD): 2 lines @ 24 characters/line. • 6-button Keypad: ENTER, CLEAR, (4X) navigation • LED system status display showing: <ul style="list-style-type: none"> ○ Operational status indicators: Unit, Remote, Stored Event ○ Online status indicators: Traffic or Redundant Modem | | |
| Audible Alarm | Programmable to activate following various changes of state | | |
| Common faults | Dry relay contacts | | |
| AC Prime Power | Two independent inputs: 90 to 264 VAC, 50/60 Hz, at 25 Watts | | |
| DC Power | Two independent inputs: -48 VDC, at 25 Watts | | |
| Dimensional Envelope | 19W x 11.2D x 3.75H inch (2RU) (48.26W x 28.4D x 8.9H cm) | | |
| Weight | ~ 10 lbs (~ 9.07kg) | | |
| CE Mark | EMC and Safety | | |
| Supported User Data Interfaces (by TMI) | TMI | Connector | Data Type |
| | CRS-316 | DB-25M | EIA-530/422/V.35, EIA-232 |
| | | RJ-45 | GigE |
| | CRS-325 | DB-15F | G.703 Balanced |
| | | (2X) BNC | G.703 Unbalanced/ASI |
| | CRS-336 | HD-50F | HSSI |
| | | RJ-45 | GigE |
| CRS-365 | (4X) RJ-45 | E1 Bal (only) | |
| CRS-515 | (4X) RJ-45 | 10/100/1000 Ethernet | |

| Characteristic | Requirement | | | |
|--|----------------|------------------------------|---------------------------|---------------------------|
| | Modem | Data Interface | TMI | RMI |
| Supported User Data Interfaces (To TMI/RMI, by Modem) | CDM-Qx/QxL | EIA-530/422/V.35, EIA-232 | CRS-316 | CRS-305 |
| | | G.703 Bal / Unbal | CRS-325 | CRS-305 |
| | | HSSI | CRS-336 | CRS-305 |
| | | Quad E1 | CRS-365 | CRS-305 |
| | SLM-5650/5650A | MIL-STD-188-114, EIA-530 | CRS-316 | CRS-307 |
| | | GigE | CRS-316 <i>or</i> CRS-336 | CRS-306 <i>or</i> CRS-307 |
| | | G.703 Bal / UnBal | CRS-325 | CRS-306 |
| | | HSSI | CRS-336 | CRS-306 <i>or</i> CRS-307 |
| | | 4-Port Ethernet | CRS-515 | CRS-505 |
| | | | | |

1.5.2 CRS-281x IF Switch Module Specifications

| Characteristic | Requirement CRS-281 (70/140MHz) | Requirement CRS-281A/CRS-281L (L-Band) |
|--|---|--|
| Tx/Rx Operating Freq | 50 to 180 MHz | 950-2000 MHz |
| Tx/Rx Connectors | <ul style="list-style-type: none"> TNC (female) with 50Ω path BNC (female) with 50Ω or 75Ω path | N-Type (female) with 50Ω path |
| Return Loss | 18 dB | > 10 dB on external IF ports |
| Transmit IF Loss/Flatness: Tx In To Tx Uplink Out BU In To Any Uplink Out | < 1.5 dB over operating freq < 1.5 dB over operating freq | Tx IF note: Switched by RF relay (1.5 dB max loss, 40 dB min ON/OFF isolation) |
| Receive IF Loss/Flatness: Rx Downlink In To Rx Out Any Downlink In To BU Out | < 5 dB over operating freq < 5 dB over operating freq | Rx IF note: Passive power splitting (7 dB max loss) |
| Tx to Tx Channel Isolation | > 50 dB | > 50 dB |
| Tx to Rx Channel Isolation | > 60 dB | 90dB min |
| IF Switch Power | From CRS-311 chassis | From CRS-311 chassis |
| IF, BUC/LNB DC, 10 MHz and BUC FSK Switching | N/A | CRS-281A (CDM-QxL only) |

1.6 Dimensional Envelopes

Figure 1-22 shows the dimensional envelope for the CRS-311 1:1 Redundancy Switch.




Figure 1-22. CRS-311 Dimensional Envelope

Chapter 2. INSTALLATION

2.1 Unpacking and Inspection



Be sure to keep all shipping materials for the carrier's inspection.

| Step | Procedure |
|------|--|
| 1 | Inspect shipping containers for damage. |
| 2 | If shipping containers are damaged, keep them until the contents of the shipment have been carefully inspected and checked for normal operation. |
| 3 | Remove the packing list from the outside of the shipping carton. |
| 4 | Open the carton and remove the contents. |
| 5 | Check the contents against the packing list to verify completeness of the shipment. |
| 6 | If damage is evident, contact the carrier and Comtech EF Data immediately and submit a damage report. |
| 7 | If the unit needs to be returned to Comtech EF Data, use the original shipping container. |

2.2 Rack Mounting

The CRS-311 is constructed as a 2RU-high, rack-mounting chassis. Rack handles are provided to facilitate removal and placement into a rack.

Mount the Switch in the rack using the mounting holes on the front panel. Use the front panel screw holes **only**. DO **NOT** install rack slides to the side of the CRS-311 chassis – contact Comtech EF Data if there are questions about rack supports.

Figure 2-1 provides a “cut-away” side view of a typical rack configuration for modems combined with the CRS-311. Since the Switch itself is relatively passive, no additional clearance is needed between it and either modem.

It is important to ensure that there is adequate clearance for ventilation in the rack – in rack systems where there is high heat dissipation, provide forced-air cooling by installing top- or bottom-mounted fans or blowers.



Do not allow the internal rack temperature to exceed 50°C (122° F).




Figure 2-1. Typical Rack-mounted Configuration

Chapter 3.

CABLES AND CONNECTIONS

3.1 Overview

All cables for connecting the CRS-311 1:1 Redundancy Switch to the CDM-Qx/QxL and SLM-5650/5650A modems or within the system are available from Comtech EF Data. These cables can be ordered at the same time the order is placed for the CRS-311.

If fabricated by the customer, the cables required between each modem and Switch plug-in RMI or TMI card should be of shielded, twisted-pair construction, with the grounded shield bonded to the back shell. All data cables should be wired correctly using the pinout and connection information as specified in **Appendix A. CABLE DRAWINGS**.



Leave the Switch and all modems powered off until all connections are ready.

Once the Switch and all the modems have been mounted, the User must properly attach all required cabling. In most cases the modem accepts the male end of the cable, while connectors on the RMI or TMI card accepts the female end of the cable in the section of the card labeled “Modem Interface.”

Refer to the subsections in **Sect. 1.4 Description of CRS-311 Features** for detailed information on these interfaces. Illustrations featured throughout this chapter provide cabling configuration examples for RMI or TMI interfaces – i.e., the interconnection of a Redundant Modem to a Switch RMI card, or the interconnection between a Switch TMI card and a Traffic Modem. The step-by-step process for connecting a variety of Switch and modem configurations is also illustrated in this chapter.

3.2 CDM-Qx/QxL Modem Connections

- **RS-485 Connections – CRS-311 to Modems**
- **Control ‘Y’ Cable Connections – CRS-311 to Modems**
- **Traffic Data Connections – CRS-311 to Modems**
- **User Data Connections – CRS-311 to User**
- **IF Connections – User to CRS-281x Module to Modems**

3.2 CDM-Qx/QxL Modem Connections

If adding a modem to an *operating* 1:1 system, care needs to be taken to not interfere with the existing *traffic*. The cabling, power-up sequence and COMMs connections must be correct to avoid contention in the system from the modem Tx carrier.

As shown in **Figure 3-2** through **Figure 3-6**, the CA-0000009 Control ‘Y’ Cable provides fault information from the modem and IF-Mute to the modem, and is therefore always required.

3.2.1 RS-485 Connections – CRS-311 to Modems

The DB-9 RS-485 Multi-drop Cable provides the communication path between the Switch and the modems. There are two RS-485 cables types available: the standard CA-0000096 shielded cable to guard against EMC (Electromagnetic Compatibility) concern, or the optional CA-0000095 ribbon cable. Both are available from Comtech EF Data.

Refer to **Figure 3-1** to connect the standard CA-0000096 or optional CA-0000095 RS-485 Multi-drop Cable between the CRS-311 and each CDM-Qx/QxL as follows:

- Connect and secure (1) each CA/WR11418-1 RS-485 Terminator on each far-end of the RS-485 Multi-drop Cable.
- Connect and secure one end of the CA/WR11419-1 9-pin Null Modem Cable to the DB-9F connector labeled “485 Pass-Through” on the CRS-311’s CRS-230 System Controller.
- Connect and secure the appropriate RS-485 Multi-drop Cable to the CDM-Qx/QxL and to the DB-9M connector on the Null Modem Cable.

3.2.2 Control ‘Y’ Cable Connections – CRS-311 to Modems

All traffic data configurations require the CA-0000009 Control ‘Y’ Cable connected between the CRS-311 RMI and TMI and to each CDM-Qx/QxL as follows:

- HD-15F connector labeled “J1” on the RMI or TMI, to
- DB-15M connectors labeled “Alarms” on the CDM-Qx/QxL modulator and demodulator cards (located on the modem chassis rear panel):
 - Control ‘Y’ Cable connector labeled “J1” goes to the modulator “Alarms” connector.
 - Control ‘Y’ Cable connector labeled “J2” goes to the demodulator “Alarms” connector.

3.2.3 Traffic Data Connections – CRS-311 to Modems

Connect and secure the cables between the CRS-311 and each CDM-Qx/QxL:

If EIA-530 V.35/EIA-232 is the traffic data type, refer to **Figure 3-2** to connect and secure the CA/WR0066-4 25-pin Control and Data Cable as follows:

- DB-25M connector labeled “P2” on the RMI or “P1” on the TMI, to
- DB-25F connector labeled “EIA-530” on the demodulator.

If balanced G.703 is the traffic data type, refer to **Figure 3-3** to connect and secure the CA/WR9038-4 15-pin Data Cable as follows:

- DB-15M connector labeled “P1” on the RMI or TMI, to
- DB-15F connector labeled “G.703” on the demodulator.

If Unbalanced G.703 is the traffic data type, refer to **Figure 3-4** to first connect and secure the CA/WR0813-4 BNC Tx Cable as follows:

- BNC connector labeled “J4” on the RMI or “J3” on the TMI, to
- BNC connector labeled “Tx” on the demodulator.

Next, connect and secure the CA/WR0813-4 BNC Rx Cable as follows:

- BNC connector labeled “J3” on the RMI or “J5” on the TMI, to
- BNC connector labeled “Rx” on the demodulator.

If HSSI is the traffic data type, refer to **Figure 3-5** to connect and secure the CA/WR9189-4 HSSI Data Cable as follows:

- HSSI connector labeled “J2” on the RMI or “J3” on the TMI, to
- HSSI connector labeled “HSSI” on the demodulator.

If Quad E1 is the traffic data type, refer to **Figure 3-6** to first connect and secure the CA/WR13018-2 Quad E1 RMI Data Cable as follows:

- DB-15M connector labeled “P1” on the RMI, to
- <4X> RJ-48 connectors labeled “Port 1” through “Port 4” on the Redundant Modem.

Next, connect and secure the <4X> PP/CAT5FF3FTGY Quad E1 TMI Data Cables as follows:

- RJ-48 connectors labeled “Port 1” through “4” on the TMI, to
- RJ-48 connectors labeled “Port 1” through “Port 4” on the Traffic Modem.

3.2.4 User Data Connections – CRS-311 to User

The User’s traffic data from multiplexing equipment or a test data generator should connect to the connectors on the TMI labeled “User Data Interface”. This interface replaces the direct connection to the Traffic Modem’s “Data Interface” connectors.

Because the Redundant Modem’s function is to replace a faulted terrestrial modem, the RMI does not have a User Data Interface.

Refer to **Sect. 1.4.3 CDM-Qx/QxL, SLM-5650/5650A Modem Interface Cards** for detailed information on the RMI and TMI cards available for use with the CDM-Qx/QxL modem.




Figure 3-1. CDM-Qx/QxL Cabling Example – RS-485 Multi-drop Cable




Figure 3-2. CDM-Qx/QxL Control 'Y' and EIA-530/RS-232 Traffic Data Cables





Figure 3-3. CDM-Qx/QxL Control 'Y' and Balanced G.703 Traffic Data Cables

**CDM-Qx/QxL Traffic Modem
connected to CRS-325 TMI**



**CDM-Qx/QxL Redundant Modem
connected to CRS-305 RMI**

Figure 3-4. CDM-Qx/QxL Control 'Y' and Unbalanced G.703 Traffic Data Cables




Figure 3-5. CDM-Qx/QxL Control and HSSI Traffic Data Cables




Figure 3-6. CDM-Qx/QxL Control and Quad E1 Traffic Data Cables

3.2.5 IF Connections – User to CRS-281x Module to Modems

The CRS-281x module connects the online modulator's Tx IF signal to the User's RF up-converter. It also passively splits the receive IF signal to provide both demodulators with the same IF signal coming from the LNB, thus reducing switching time.

For 70/140MHz IF switching, the CDM-Qx uses the CRS-281 IF Switch Module with either 50Ω or 75Ω BNC connectors (**Figure 3-7**).

The CRS-281A IF Switch Module is intended for use with the CDM-QxL for L-Band with Type 'N' connectors (**Figure 3-8**). This model also switches all of the BUC and LNB interface signals that are multiplexed onto the transmit and receive coaxial cables, including:

- Tx and Rx L-Band signals
- 10 MHz reference to BUC and LNB
- DC Power to BUC and LNB
- FSK signaling to the BUC



To prevent problems resulting from an impedance mismatch, ensure that the impedance for the modem's cables and combiner are the same.

Refer to **Figure 3-7** and **Figure 3-8** to connect and secure the IF cable pairs –PL/0946-1 50Ω or PL/0813-4 75Ω Type 'BNC' or CA/RF10453-4 Type 'N' – between the User's up-/down-converters, CRS-311, and CDM-Qx/QxL modems as follows:

Traffic Modem Connections:

- From the "Rx" connector on the CDM-Qx/QxL to the connector labeled "J1 Rx" on the CRS-281x Switch Module, and
- From the "Tx" connector on the CDM-Qx/QxL to the connector labeled "J2 Tx" on the CRS-281x Switch Module.

User Connections:

- From the User's down-converter to the connector labeled "J3 Rx" on the CRS-281x Switch Module, and
- From the User's up-converter to the connector labeled "J4 Tx" on the CRS-281x Switch Module.

Redundant Modem Connections:

- From the "Rx" connector on the CDM-Qx/QxL to the connector labeled "J5 Rx" on the CRS-281x Switch Module, and
- From the "Tx" connector on the CDM-Qx/QxL to the connector labeled "J6 Tx" on the CRS-281x Switch Module.




Figure 3-7. CDM-Qx IF Cabling Example – CRS-281 (70/140 MhZ, 50Ω or 75Ω BNC)

3.3 SLM-5650/5650A Modem Connections

- **Control Cable Connections – CRS-311 to Modems**
- **Serial Traffic Data Connections – CRS-311 to Modems**
- **Ethernet Traffic Data Connections – CRS-311 to Modems**
- **User Data Connections – CRS-311 to User**
- **Overhead Data Connections – CRS-351 Module to User**
- **IF Cable Connections – User to CRS-281x Module to Modems**

3.3 SLM-5650/5650A Modem Connections

If adding a modem to an *operating* 1:1 system, care needs to be taken to not interfere with the existing Traffic Modem. The cabling, power-up sequence, and communication connections must be correct to avoid contention in the system from the modem Tx carrier.

3.3.1 Control Cable Connections – CRS-311 to Modems

The CA/WR12136-2 Control Cable provides the serial communication path between the Switch and the modems and controls the modem's external Tx IF-mute control line, and is therefore always required.

To provide User access to the AGC and I&Q outputs of the modem, the CA/WR12842-4 (4' length) and CA/WR12842-6 (6' length) Control 'Y' Cables, sold separately, are available for use in place of the CA/WR12136-2 Control Cable. See **Appendix A. CABLE DRAWINGS** for detailed information about these optional cable assemblies.

Refer to **Figure 3-9**, **Figure 3-10**, and **Figure 3-11** to connect and secure the CA/WR12136-2 Control Cable (or the CA/WR12842-4 Control 'Y' Cables, if used) as follows:

- HD-15F connector labeled "J1" on the RMI or TMI, and
- HD-15F connector labeled "J9 Auxiliary" on the SLM-5650/5650A.

3.3.2 Serial Traffic Data Connections – CRS-311 to Modems

If HSSI is the traffic data type, refer to **Figure 3-9** to connect and secure the CA/WR9189-4 HSSI Data Cable as follows:

- HSSI (HD-50F) connector labeled "J2" on the RMI or "J3" on the TMI, and
- HSSI (HD-50F) connector labeled "J7 HSSI" on the SLM-5650/5650A.

Referring to Figure 3-10:

If balanced G.703 is the traffic data type (when available via the optional G.703 Interface Module), connect and secure the CA/WR9038-4 Balanced G.703 Data Cable as follows:

- DB-15M connector labeled "P1" on the RMI or TMI, and
- DB-15F connector labeled "J1 Bal Data" on the SLM-5650/5650A.

If Unbalanced G.703 is the traffic data type (when available via the optional G.703 Interface Module), connect and secure the pair of PL/0813-4 Data Cables between the SLM-5650/5650A and the CRS-311 as follows:

- BNC connectors labeled "J4 Tx" on the RMI or "J3 Tx" on the TMI to BNC connectors labeled "J3 Rx" on the SLM-5650/5650A, and
- BNC connectors labeled "J3 Rx" on the RMI or "J5 Rx" on the TMI to BNC connectors labeled "J2 Tx" on the SLM-5650/5650A.

If EIA-530 is the traffic data type, refer to **Figure 3-11** to connect and secure the A/WR0066-4 Data Cable as follows:

- DB-25M connector labeled "P2" on the RMI or "P1" on the TMI, and
- DB-25F connector labeled "J6 EIA530" on the SLM-5650/5650A.

When Ethernet is the traffic data type, refer to **Figure 3-9**, **Figure 3-12**, or **Figure 3-13** to connect and secure all Cat5 Data Cables PP/CAT5FF3FTGY as follows:

- **For single-port Ethernet in Bridge Mode (when available via the optional GigE Interface card)**, as shown in **Figure 3-9**:
 - RJ-45 connector labeled “J5” on the RMI or TMI, to
 - RJ-45 connector labeled “J1” on the optional GigE Interface card.
- **For multi-port Ethernet in Bridge Mode (when available via the optional Network Processor Interface Module)**, as shown in **Figure 3-12**:
 - RJ-45 connector labeled “Port 2” through “Port 4” on the RMI or TMI, to
 - RJ-45 connector labeled “Port 2” through “Port 4” on the optional Network Processor Interface Module.



Do not connect to Port 1 on the RMI, TMI, or optional Network Processor Interface Module when operating in Ethernet Bridge Mode.

- **For multi-port Ethernet in Router Mode (when available via the optional Network Processor Interface Module)**, as shown in **Figure 3-13**:
 - RJ-45 connector labeled “Port 1” through “Port 4” on the RMI or TMI, to
 - RJ-45 connector labeled “Port 1” through “Port 4” on the optional Network Processor Interface Module.

3.3.3 User Data Connections – CRS-311 to User

The User’s traffic data from an external router, multiplexing equipment or test data generator should connect to the connectors on the TMI labeled “User Data Interface”. This interface replaces the direct connection to the Traffic Modem’s “Data Interface” connectors.

Because the Redundant Modem’s function is to replace a faulted Traffic Modem, the RMI does not have a User Data Interface.

Refer to **Sect. 1.4.3 CDM-Qx/QxL, SLM-5650/5650A Modem Interface Cards** for detailed information on the RMI and TMI cards available for use with the SLM-5650/5650A modem.




Figure 3-9. SLM-5650/5650A Control and HSSI, Ethernet Traffic (Single Port Bridge Mode) Data Cables




Figure 3-10. SLM-5650/5650A Control and G.703 Traffic Data Cables




Figure 3-11. SLM-5650/5650A Control and EIA-530 Traffic Data Cables




Figure 3-12. SLM-5650/5650A Control and Ethernet Traffic (Multi-Port Bridge Mode) Data Cables




Figure 3-13. SLM-5650/5650A Control and Ethernet Traffic (Multi-Port Router Mode) Data Cables


3.3.4 Overhead Data Connections – CRS-351 Module to Modems

The User's equipment should be connected to the "P1 User Interface" port on the CRS-351 module. This replaces the direct connection to the Traffic Modem's "P1 Overhead Data" port.

Refer to **Figure 3-14** to connect and secure the CA-000006 Control 'Y' Cable between the CRS-351 module and the SLM-5650/5650A modems as follows:

- DB-50F connector labeled "J1 Modem Adapter "Y" Cable" on the CRS-351 module, and
- DB-25M "P1 Overhead Data" connectors on the SLM-5650/5650A Traffic and Redundant modems.

SLM-5650/5650A Traffic Modem connected to CRS-351



SLM-5650/5650A Redundant Modem connected to CRS-351

Figure 3-14. SLM-5650/5650A Overhead Data Cables

3.3.5 IF Connections – User to CRS-281x to Modems

The CRS-281x modules connect the online modulator's Tx IF signal to the User's RF up-converter. It also passively splits the receive IF signal to provide both demodulators with the same IF signal coming from the LNB, thus reducing switching time.

For 70/140MHz IF switching, the SLM-5650/5650A uses the CRS-281 IF Switch Module with 50Ω TNC connectors (**Figure 3-15**).

The CRS-281L IF Switch Module is intended for use with the SLM-5650/5650A for L-Band with N-type connectors (**Figure 3-16**).

Refer to **Figure 3-15** and **Figure 3-16** to connect and secure the IF cable pairs – CA/3005-3 TNC or CA/RF10453-4 Type-N – between the User's up-/down-converters, CRS-311, and SLM-5650/5650A modems as follows:

Traffic Modem Connections:

- From the “J3 Rx” (70/140 MHz) or “J4 Rx” (L-Band) connector on the SLM-5650/5650A, to the connector labeled “J1 Rx” on the CRS-281x Switch Module, and
- From the “J1 Tx” (70/140 MHz) or “J2 Tx” (L-Band) connector on the SLM-5650/5650A to the connector labeled “J2 Tx” on the CRS-281x Switch Module.

User Connections:

- From the User's down-converter to the connector labeled “J3 Rx” on the CRS-281x Switch Module, and
- From the User's up-converter to the connector labeled “J4 Tx” on the CRS-281x Switch Module.

Redundant Modem Connections:

- From the “J3 Rx” (70/140 MHz) or “J4 Rx” (L-Band) connector on the SLM-5650/5650A to the connector labeled “J5 Rx” on the CRS-281x Switch Module, and
- From the “J1 Tx” (70/140 MHz) or “J2 Tx” (L-Band) connector on the SLM-5650/5650A to the connector labeled “J6 Tx” on the CRS-281x Switch Module.

Mixed IF Bands for Tx/Rx:



The SLM-5650/5650A modem permits simultaneous operation of the Tx IF and Rx IF bands at 70/140 MHz and L-Band frequencies, independent of one another. If the user wants the Tx and Rx to be of different IF bands, the CRS-281x module must be selected based on the Tx IF band. An external splitter is then used for the Rx IF band when that side differs from the Tx IF band – refer to Figure 3-17 and Figure 3-18 for these mixed-use configuration examples.




Figure 3-17. SLM-5650/5650A Mixed IF Band Cabling Example – CRS-281 'TNC' (70/140 MHz Tx, L-Band Rx)




Figure 3-18. SLM-5650/5650A Mixed IF Band Cabling Example – CRS-281L (70/140 MHz Tx, L-Band Rx)

Chapter 4. MODEM AND SWITCH CONFIGURATION

4.1 Modem Configuration

4.1.1 Modem Power

Connect the power cords of each modem to a power supply and turn both modems **ON**.

4.1.2 Modem Firmware and Hardware Requirements

For the CRS-311 1:1 Redundancy Switch to operate correctly, it is important that the Traffic Modem and the Redundant Modem must be of the same model. In addition to matching hardware requirements, the Redundant Modem must have the same firmware revision and installed options so that the it can properly mimic operation of the Traffic Modem.

Permitted modem models and firmware versions are as follows:

| Modem | Modem Firmware Version | GigE Firmware Version |
|------------|------------------------|-----------------------|
| CDM-Qx/QxL | 1.1.4 or later | N/A |
| SLM-5650 | 1.4.2 or later | 1.1.2 |
| SLM-5650A | 1.1.2 or later | 1.1.2 |

For operation of the SLM-5650/5650A with the optional 4-Port Ethernet Network Processor (NP) Module:

| Modem | Modem Firmware Version | NP Firmware Version |
|-----------|------------------------|---------------------|
| SLM-5650 | 1.5.1 or later | 1.5.1 |
| SLM-5650A | 1.1.8 or later | 1.5.1 |



If the modem does not meet these listed requirements, contact Comtech EF Data. Flash firmware upgrades are free and may be downloaded from the CEFD Web page. Hardware revision upgrades must be performed at CEFD.

4.1.2.1 Flash Upgrading

For detailed instructions on upgrading modem firmware via flash upgrade, refer to the pertinent modem’s *Installation and Operation Manual*.

4.1.3 Modem Operational Configuration

This chapter assumes user familiarity with the menu navigation and configuration parameter selection methods using the individual modems’ front panel menu. For detailed instructions on changing configuration settings using the front panel keypad and menus, refer to the *Front Panel Operation* chapter in the pertinent modem’s *Installation and Operation Manual*.

Using the modem’s manual, configure the Traffic Modem for the proper Rx and Tx IF, power settings, modulation, code rates, and traffic data settings.

For User-to-Switch or User-to-Modem addressing schemes, see **Appendix B. Addressing Scheme Information**.

4.1.4 Modem Redundancy Configuration

4.1.4.1 Switch to CDM-Qx/QxL Redundancy Configuration

The CRS-311-to-CDM-Qx/QxL redundancy configuration uses an external RS-485 multi-drop communication cable.

The CDM-Qx/QxL can be configured in many different ways, but for a CRS-311 application, the CDM-Qx/QxL should be configured **only** as one modem – i.e., containing one modulator and one demodulator card, which must be **grouped** to act as a modem. See the *CDM-Qx/QxL Installation and Operation Manual* for more information.

As shown in **Figure 4-1**, Modem 1 resides in Slots 1 and 2. Modem 2 is contained in Slots 3 and 4. The Switch can use either modem.




Figure 4-1. CDM-Qx/QxL Serial Communication Configuration

The CDM-Qx/QxL chassis has a configurable RS-485 base address – which applies for Modem 1 – and an offset, which is added to the base-address if addressing Modem 2. The RS-485 addresses are selected via the front panel menu: **CONFIG → REMOTE**.

The Switch addresses each CDM-Qx/QxL modem based on which TMI it is attached to, with addresses at increments of 100. For example, with a Switch with address 0, the Qx/QxL Traffic Modem has address 0100, and the Redudant Modem uses address 1100. See **Figure 4-2** and **Appendix B. Addressing Scheme Information** for more information.

Once the addressing scheme is understood, proceed as follows:

| Step | Procedure |
|------|--|
| 1 | Configure COMMs on each modem via the <i>modem</i> front panel menu as follows: CONFIG → REMOTE: RS-485-4W, 9600 baud, format 8-N-1. |
| 2 | Set the RS-485 base address and offset, per Appendix B. Addressing Scheme Information . |

Refer to the *CDM-Qx Installation and Operation Manual* for detailed configuration information.




Figure 4-2. CDM-Qx/QxL / CRS-311 RS-485 Scheme

Note: In this example, the RS-485 offset address does not effect Modem #1, so the offset can be 1-99 without affecting other Modem’s RS-485 addresses.

4.1.4.2 Switch to SLM-5650/5650A Redundancy Configuration

The CRS-311 communicates to the Redundant and Traffic modems via a serial TTL bus contained within the HD-15 “J9 Auxiliary” connector on the modem’s rear panel. An HD-15M to HD-15F Control cable connects each modem to the CRS-311.

To configure SLM-5650/5650A and CRS-311 for 1:1 redundancy:

| Step | Procedure |
|------|---|
| 1 | If the terrestrial data type is Ethernet, for each modem, enter a unique IP Address for the optional GigE Interface card that is on the same subnet: CONFIG → MODE → INTERFACE → GIGABIT ETHERNET |
| 2 | The SLM -5650/5650A must have the COMMs configured to redundancy. Configure the COMMS of each of the modems via the <i>modem</i> front panel menu: <ul style="list-style-type: none">Select the interface for operation with the CRS-311: SELECT: Configure → Config: Remote → Remote Control: SerialConfig → Remote Control:Interface → M&C Bus Interface: TTL (Switch) → The active local M&C Bus Address should now be displayed. |
| 3 | Power down both SLM-5650/5650As. |
| 4 | Power up both SLM-5650/5650As. Verify that the Traffic Modem is ONLINE . |

Refer to the *SLM-5650* or *SLM-5650A Installation and Operation Manual* for detailed configuration information.

4.2 Switch Configuration

4.2.1 Switch Power

Connect the power cords as follows:

| Step | Procedure |
|------|--|
| 1 | Each CRS-311 is supplied with two power cords. Connect the female end of the supplied power cords (one to each power supply power input). |
| 2 | Plug both power cords into the power source(s). The CRS-311 will power ON . <i>Note: The auto-sensing power supplies do not require any adjustments.</i> |

If only one power supply card is used, mask the fault for the unused power supply as follows:

| Step | Procedure |
|------|--|
| 1 | Go to the CONFIG: MASKS → SW-ALARMS menu. |
| 2 | Select to mask the unused power supply. |

Note: The power supplies contain two fuses, one each for line and neutral connections (or L1, L2 where appropriate). These are contained within the body of the connector, behind the small plastic flap.



For continued operator safety, always replace the fuses with the correct type and rating. For 115/230 volt AC operation, use T1A (slow-blow) 20 mm fuses.

4.2.2 Flash Updating

The CRS-311 eliminates the need for updating firmware by physically replacing EPROMs. Instead, the CRS-311 uses ‘flash memory’ technology internally. This makes software upgrading very simple, and updates can now be sent via the Internet (**Figure 4-3**), E-mail, or on disk. The upgrade can be performed without opening the unit by simply connecting the Switch to the serial port of a computer. New firmware can be uploaded to the unit from an external PC via the Internet as follows:

1. **Go online to:** www.comtechefdata.com
2. **Click on:** Support
3. **Click on:** Software Downloads
4. **Click on:** Flash Update Files
5. **Click on:** <dir> CRS311
6. **Select:** For_CD-Qx or For_SLM-5650*

(*Note: Choices shown are representative of upgrades available via the Web as of 10/2008. These selections are updated periodically. Contact Comtech EF Data Customer Support for questions regarding the availability of support files for your specific product.)




Figure 4-3. Flash Update via Internet

The latest two releases of firmware code and the Uploader are available in a Zip file. The Upload utility is a free software utility designed to run under Windows 95/98/2000® or Windows NT®.

The Zip file should be downloaded to the User's computer hard disk, and then unzipped:

- The utility program is called **CCCFLASH.EXE**
- The firmware file is called, for example, **fw-0069-.ccc**

The User should connect an RS-232 serial cable (details are shown in the cable details box on the Uploader screen, as well as in **Appendix A. CABLE DRAWINGS**) from the computer to the remote control port of the Switch.

Run the **Upload** utility. The User should follow the instructions presented on the screen, and the upload will take place automatically.

Following the successful upload process, the Switch will automatically re-start, running the new version of firmware. During this process, the non-volatile RAM storing the configuration of the Switch will be erased, so the User is then required to re-enter the desired configuration.

4.2.2.1 Flash Update Help

Full on-line help is provided with CCCFLASH.EXE. Additionally, a reference guide is available by selecting the **Flash Update Instructions** link on the *Software Upgrade* Web page (**Figure 4-3**). Please contact Comtech EF Data Customer Support if you have questions or need additional assistance.

4.2.3 CRS-311 Front Panel Configuration

The CRS-311 should show a **GREEN** “Unit Status” LED. If it is **RED**, go to **MONITOR → SW-ALARM** to view the faults. Ensure that the preceding Redundant Modem setup is complete and that it is operating correctly before proceeding. Use the front panel keypad and display to configure the Switch as described in this section.

The **Switch Status** LED will turn **RED**, until the Switch has polled the Traffic Modem and correctly programmed the Traffic Modem configuration into the Redundant Modem. Once the programming is completed successfully, the **RED** LED will turn **GREEN**.

The Redundant Modem may take several seconds to configure. If the LED remains **RED**, check the communication status using the menus to investigate the problem:

MONITOR → COMMS or **MONITOR → SW-ALARM**

Another option is to view the I/O using **MONITOR → IO**. This menu will show the actual messages to and from the modem. If there are no responses from a modem, check the addressing scheme carefully and verify correct modem communication setups. Communication is slowed to aid viewing.

For modems: Use the **INFO** and **MONITOR** menus to view the status of the modems, in addition to viewing the LEDs.

For Switch: Use **MONITOR → COMMS** to verify the modems that are responding via remote control.

For real-time monitoring: Use **MONITOR → IO** to verify the modems that are responding via remote control. Communication is slowed to aid viewing.



Do not leave the CRS-311 in this view.

4.2.3.1 Set Operation Mode

The CRS-311 was shipped in the **Auto-Off (i.e. Manual) operating mode**. This setting causes the Stored Event LED to blink. The system is operational; however, it is still operating in **Manual** mode. In the menu, this manual mode is called **Auto-off**. While in **Manual** mode, the User can manually select which modem (Traffic Modem or Redundant Modem) will be bridged or backed up.

While in **Manual** mode, the Switch does not *automatically* react to Traffic Modem failures it detects. Comtech EF Data recommends that an unattended system be configured to operate in **Auto On** mode.

When **Auto On** mode is enabled, when a fault occurs, the online modem is first bridged by the offline modem, and then backed up.

To enable **Auto On** mode:

| Step | Procedure |
|------|---|
| 1 | Go to the CONFIG → AUTO menu and select AUTO ON mode. |
| 2 | Verify that the Stored Event LED stops blinking. |

4.2.3.2 Set Holdoff Period

A *holdoff period* prevents unwarranted backups due to an intermittent fault. When in **Auto** mode, additional delays may be introduced to the backup procedure by setting the number of seconds for "holdoff" before the faulted Traffic Modem cedes operation to the Redundant Modem (*backup*), or operation is returned from the Redundant Modem back to the Traffic Modem (*restore*).

The process is further explained:

If a fault occurs in the Traffic Modem, and the Redundant Modem operation is fault-free, *backup* is initiated once the configured **Backup Holdoff Period** lapses. However, if the fault clears within the holdoff's configured timeframe, no transfer of operation occurs.

Similarly, if a fault occurs in the Redundant Modem while it is online, and the Traffic Modem's operation is fault-free, *restore* is initiated once the configured **Restore Holdoff Period** lapses.

The default holdoff period is 10 seconds (a minimum of 1 second and a maximum of 99 seconds is allowed).

4.2.3.2.1 Set Backup Holdoff Period

If the Traffic Modem fails, the Switch waits for the backup holdoff time to determine two things:

- 1) Does the Traffic Modem remain faulted?
- and*
- 2) Is the Redundant Modem not exhibiting the same fault?

If the answer is *yes* to both questions for the entire Backup Holdoff Period, then the Switch first bridges the faulted Traffic Modem with the Redundant Modem. If the fault is sustained, then the switchover to the Redundant Modem is completed and the Redundant Modem carries the traffic.

There will be no switchover if the Redundant Modem is faulted. Ensure that the Holdoff times are long enough (default 10 seconds) for the Redundant Modem to be configured and to lock onto the signal.

Note: If the CDM-Qx/QxL configuration includes Carrier-in-Carrier® this holdoff time should be no less than 8 seconds.

To set the **Backup Holdoff Period**:

| Step | Procedure |
|------|---|
| 1 | Go to the CONFIG → HOLDOFFS menu. |
| 2 | Change the BACKUP HOLDOFF to any number in the range of 1 to 99 seconds. |

4.2.3.2.2 Set Restore Holdoff Period

The "**Restore Holdoff**" setting, which is also programmable from 1 to 99 seconds, determines the Switch's ability to automatically put the backed up Traffic Modem online again if its fault clears.

Normally, the failed Traffic Modem taken offline remains offline indefinitely. If the fault clears, traffic will be returned to the unit (in **Auto** mode) only if the Redundant Modem fails.

To set the **Restore Holdoff Period**:

| Step | Procedure |
|------|--|
| 1 | Go to the CONFIG → HOLDOFFS menu. |
| 2 | Change the RESTORE HOLDOFF to any number in the range of 1 to 99 seconds. |

4.2.3.3 Set Alarm Masking


Another way to adjust the Switch's reaction in Auto mode is to mask modem faults. The User may disable modem Rx, Tx or both fault types so that the Switch does not react to them. This masking prevents the Switch from taking automatic action and prevents the logging of the faults in the stored events list. These masks are global to all the modems attached to the Switch.

To set **Alarm Masks**:


| Step | Procedure |
|------|--|
| 1 | Go to CONFIG → MASKS → MODEM ALARMS . |
| 2 | Set the mask parameters as desired. |

Chapter 5. CONNECTOR PINOUTS

5.1 CRS-230 Controller Connectors



5.1.1 IF Switch Control – DB-25M Connector



The IF Switch Control connector is not used on the CRS-311.

5.1.2 485 Pass-Through – DB-9F Connector



Table 5-1 indicates the pinout for the 485 Pass-Through connector, used only with the CDM-Qx/QxL modems.

Table 5-1. 485 Pass-Through User Data Connector

| Pin | Description | Direction |
|-----|---|-----------|
| 1 | Ground | |
| 2 | RS-232 Transmit Data | Out |
| 3 | RS-232 Receive Data | In |
| 4 | Reserved - do not connect to this pin | |
| 5 | Ground | |
| 6 | RS-485 Receive Data B (see note) | In |
| 7 | RS-485 Receive Data A (see note) | In |
| 8 | RS-485 Transmit Data B | Out |
| 9 | RS-485 Transmit Data A | Out |

Note: Use for 2-wire RS-485 operation.

5.1.3 Remote Control – DB-9M Connector



The DB-9M Remote Control Connector provides access to the remote control ports of the Switch for both RS-232 and RS-485. **Table 5-2** provides the pinout information.

Table 5-2. Remote Control User Data Connector

| Pin | Description | Direction |
|-----|---|-----------|
| 1 | Ground | |
| 2 | RS-232 Transmit Data | Out |
| 3 | RS-232 Receive Data | In |
| 4 | Reserved - do not connect to this pin | |
| 5 | Ground | |
| 6 | RS-485 Receive Data B (see note) | In |
| 7 | RS-485 Receive Data A (see note) | In |
| 8 | RS-485 Transmit Data B | Out |
| 9 | RS-485 Transmit Data A | Out |

Note: Use for 2-wire RS-485 operation.

5.1.4 System Alarms – DB-25F Connector



Table 5-3 indicates the pinout for the DB-25F TMI System Alarms connector.

Table 5-3. System Alarms User Data Connector

| Pin | Description |
|-----|---|
| 1 | Traffic Modem Online Status – Common for pin 6 (Note 2) |
| 14 | Not used |
| 2 | Not used |
| 15 | Not used |
| 3 | Not used |
| 16 | Not used |
| 4 | Not used |
| 17 | Not used |
| 5 | Not used |
| 18 | Not used |
| 6 | Traffic Modem Online Status – Normally Open (Note 2) |
| 19 | No Connection |
| 7 | Ground |
| 20 | Audio Indicator (Gnd = Auto On / Float = Audio Off) |
| 8 | Form C Fault Relay – Common Common for pins 9-12 and 21-24 |
| 21 | Switch Unit Fault – Normally Closed |
| 9 | Switch Unit Fault – Normally Open |
| 22 | Modem Summary Unit Fault –Normally Closed |
| 10 | Modem Summary Unit Fault – Normally Open |
| 23 | Modem Summary Tx Traffic Fault – Normally Closed |
| 11 | Modem Summary Tx Traffic Fault – Normally Open |
| 24 | Modem Summary Rx Traffic Fault – Normally Closed |
| 12 | Modem Summary Rx Traffic Fault – Normally Open |
| 25 | Not Used |
| 13 | Not Used |

Notes:

1. “Normally” refers to the NON-FAILED state.
2. Traffic Modem Online Status (Open = Online, Closed = Backup)

5.2 TMI User Data Connectors

5.2.1 RS-232/422/V.35 – DB-25F Connector (CRS-316)




Table 5-4 indicates the pinout for the DB-25F TMI User Data Interface connector (RS232/422/V.35): J2 on the CRS-316.

Table 5-4. EIA-422/530 / V.35 / Sync EIA-232 User Data Connector

| Pin | Generic Signal Description | Direction | RS-422/ RS 530 | V.35 | RS-232 | Circuit No. |
|-----|--|--------------|-------------------|--------|--------|-------------|
| 1 | Shield | - | Shield | FG | AA | 101 |
| 2 | Transmit Data A | DTE to Modem | SD A | SD A | BA | 103 |
| 3 | Receive Data A | Modem to DTE | RD A | RD A | BB | 104 |
| 4 | Request to Send A / Ready for Receiving A | DTE to Modem | RS A | RS A | | |
| 6 | DCE Ready A | Modem to DTE | DM_A | DM_A | | |
| 7 | Signal Ground | - | SG | SG | AB | 102 |
| 8 | Receiver Ready A | Modem to DTE | RR A | RLSD * | CF | 109 |
| 9 | Receive Clock B | Modem to DTE | RT B | SCR B | - | 115 |
| 10 | Receiver Ready B | Modem to DTE | RR | B | - | 109 |
| 11 | Transmit Clock B | DTE to Modem | TT B | SCTE B | - | 113 |
| 12 | Internal Transmit Clock B | Modem to DTE | ST B | SCT B | - | 114 |
| 14 | Transmit Data B | DTE to Modem | SD B | SD B | - | 103 |
| 15 | Internal Transmit Clock A | Modem to DTE | ST A | SCT A | DB | 114 |
| 16 | Receive Data B | Modem to DTE | RD B | RD B | - | 104 |
| 17 | Receive Clock A | Modem to DTE | RT A | SCR A | DD | 115 |
| 19 | Request to Send B / Ready for Receiving B | DTE to Modem | RS B | RS B | | |
| 22 | DCE Ready B | Modem to DTE | DM_B | DM_B | | |
| 23 | Not Used | | | | | |
| 24 | Transmit Clock A | DTE to Modem | TT A | SCTE A | DA | 113 |

Notes:

1. Receiver-Ready is an RS-232-level control signal on a V.35 interface.
2. 'B' signal lines are not used for RS-232 applications.
3. For X.21 operation, use the RS-422 pins, but ignore Receive Clock if the modem is DTE, and ignore Transmit clocks if the modem is DCE.

5.2.2 Balanced G.703 – DB-15F Connector (CRS-325)




Table 5-5 indicates the pinout for the DB-15F Balanced G.703 User Data Interface connector: “J6” on the CRS-325 TMI.

Table 5-5. Balanced G.703 User Data Connector

| Pin | Signal Description | Name | Direction |
|-----|----------------------------|------|-----------|
| 1* | Tx, Drop Data Input (-) | DDI- | In |
| 9* | Tx, Drop Data Input (+) | DDI+ | In |
| 2 | Ground | GND | |
| 10 | Not Used | | |
| 3* | Rx, Insert Data Output (-) | IDO- | Out |
| 11* | Rx, Insert Data Output (+) | IDO+ | Out |
| 4 | Ground | GND | |
| 12 | Drop Data Output (-) | DDO- | Out |
| 5 | Drop Data Output (+) | DDO+ | Out |
| 13 | Insert Data Input (-) | IDI- | In |
| 6 | Insert Data Input (+) | IDI+ | In |
| 14 | Not Used | | |
| 7 | Not Used | | |
| 15 | Not Used | | |
| 8 | Not Used | | |

* Use for all non-Drop and Insert and T2/E2 balanced applications.

5.2.3 Unbalanced G.703 – BNC Connectors (CRS-325)




Table 5-6 indicates the Unbalanced G.703 User Data Interface BNC connectors: “J2” and “J4” on the CRS-325 TMI.

Table 5-6. Unbalanced G.703 User Data Connectors

| BNC Connector | TMI CRS-325 Ref Des | Description | Direction |
|---------------|---------------------|-------------------|-----------|
| Rx-IDO | J4 | Rx, G.703 | Out |
| Tx-IDI | J2 | Tx, G.703 | In |
| IDI | — | Insert data input | In |
| DDO | — | Drop data output | Out |

5.2.4 HSSI – HD-50F Connector (CRS-336)




Table 5-7 indicates the HD-50F Mini-D/SCSI-II HSSI User Data Interface connector: “J2” on the CRS-336 TMI.

Table 5-7. HSSI User Data Connector

| Pin # (+, -) | Signal Function | HSSI Signal | RS613 Circuit | Circuit Direction |
|---------------------|--------------------------------------|-------------|---------------|-------------------|
| 1, 26 | Signal Ground | SG | 102 | |
| 2, 27 | Receive Timing | RT | 115 | from DCE |
| 3, 28 | DCE Available | CA | 107 | from DCE |
| 4, 29 | Receive Data | RD | 104 | from DCE |
| 5, 30 | N/A | N/A | N/A | N/A |
| 6, 31 | Send Timing | ST | 114 | from DCE |
| 7, 32 | Signal Ground | SG | 102 | |
| 8, 33 | DTE Available | TA | 108/2 | to DCE |
| 9, 34 | Terminal Timing | TT | 113 | to DCE |
| 10, 35 | N/A | N/A | N/A | N/A |
| 11, 36 | Send Data | SD | 103 | to DCE |
| 12, 37 | N/A | N/A | N/A | N/A |
| 13, 38 | Signal Ground | SG | 102 | |
| 14,15,17, 18, 39-43 | Reserved (to DCE) | | | not used |
| 16 | Tx_Carrier_Off_L ^{1,3} | CO | undefined | from DTE |
| 19, 44 | Signal Ground | SG | 102 | |
| 20 | Carrier Detect (lock) ^{1,2} | CD | undefined | from DCE |
| 21-24, 46-49 | Reserved (to DTE) | | undefined | not used |
| 25, 50 | Signal Ground | SG | 102 | |

Notes:

1. Noted signal function names are non-HSSI defined signals. On Cisco™ routers, there is no connection to those pins.
2. TTL - output.
3. TTL or RS-232 (active low) input.

5.2.5 Gigabit Ethernet (GigE) – RJ-45F Connector (CRS-316/336)




Table 5-8 indicates the pinout for the RJ-45F TMI User Data Interface connector (Gigabit Ethernet): “J4” on the CRS-316 and the CRS-336 TMIs.

Table 5-8. GigE Connector

| Pair No. | Pin No. |
|----------|---------|
| 1 | 5 |
| | 4 |
| 2 | 1 |
| | 2 |
| 3 | 3 |
| | 6 |
| 4 | 7 |
| | 8 |

5.2.6 Quad E1 – RJ-48F Connectors (CRS-365)




Table 5-9 indicates the pinout for the four (4) RJ-48F TMI User Data Interface connectors (Quad E1): Ports 1 through 4 on the CRS-365.

Table 5-9. Quad E1 Connector (Typical Ports 1 through 4)

| Pin # | Name (where Port # = Port 1, 2, 3 or 4) | Direction |
|-------|--|-----------|
| 1 | Port # Tx+ | In |
| 2 | Port # Tx- | In |
| 3 | Gnd | -- |
| 4 | Port # Rx+ | Out |
| 5 | Port # Rx- | Out |
| 6 | Gnd | -- |
| 7 | NC | -- |
| 8 | NC | -- |

5.2.7 Gigabit Ethernet (GigE) – (4X) RJ-45F Connectors (CRS-515)




Table 5-10 indicates the pinout for the RJ-45F TMI User Data Interface connectors Gigabit Ethernet (GigE) connectors: “Port1” through “Port4” on the CRS-515 TMI.

Table 5-10. GigE Connector (Typical Port 1 through Port 4)

| Pair No. | Pin No. |
|----------|---------|
| 1 | 5 |
| | 4 |
| 2 | 1 |
| | 2 |
| 3 | 3 |
| | 6 |
| 4 | 7 |
| | 8 |

5.2.8 Overhead – DB-25M Connector (CRS-351)




Table 5-11 indicates pinout for the DB-25M Overhead User Data Interface connector: “P1” on the CRS-351 Overhead Module. This connector allows for connection of EIA-422, EIA-485 and EIA-232 data interfaces for use with overhead framing. It also supports signaling for tactical applications.

Table 5-11. Overhead User Data Connector

| Pin # | Signal Function | Name |
|-------|--|---------------|
| 1 | EIA-422 Transmit Data “A”, Input | Tx Data A |
| 14 | EIA-422 Transmit Data “B”, Input | Tx Data B |
| 2 | EIA-422 Transmit Clock “A”, Output | Tx Clk A |
| 15 | EIA-422 Transmit Clock “B”, Output | Tx Clk B |
| 3 | EIA-422 Transmit Byte Sync “A”, Output | Tx Sync A |
| 16 | EIA-422 Transmit Byte Sync “B”, Output | Tx Sync B |
| 4 | EIA-422 Receive Data “A”, Output | Rx Data A |
| 17 | EIA-422 Receive Data “B”, Output | Rx Data B |
| 5 | EIA-422 Receive Clock “A”, Output | Rx Clk A |
| 18 | EIA-422 Receive Clock “B”, Output | Rx Clk B |
| 6 | EIA-422 Receive Byte Sync “A”, Output | Rx Sync A |
| 19 | EIA-422 Receive Byte Sync “B”, Output | Rx Sync B |
| 7 | Shield | Ground |
| 20 | EIA-485 Transmit Data “-“ | 485 Tx Data - |
| 8 | EIA-485 Transmit Data “+“ | 485 Tx Data + |
| 21 | EIA-422 Transmit Handover Sync “A”, Input | THS A |
| 9 | EIA-485 Receive Data “-“ | 485 Rx Data - |
| 22 | EIA-485 Receive Data “+“ | 485 Rx Data + |
| 10 | EIA-422 Transmit Handover Sync “B”, Input | THS B |
| 23 | EIA-232 Clear to Send | 232 CTS |
| 11 | EIA-232 Receive Data | 232 Rx Data |
| 24 | EIA-232 Request to Send | 232 RTS |
| 12 | EIA-232 Transmit Data | 232 Tx Data |
| 25 | EIA-422 Transmit Handover Control “A”, Input | THC A |
| 13 | EIA-422 Transmit Handover Control “B”, Input | THC B |

*For EIA-485 2-Wire Operation:

- Only two wires are required.
- Tie pins 8 and 22 together (both +).
- Tie pins 9 and 20 together (both -).

Chapter 6. FRONT PANEL OPERATION

6.1 Introduction





Figure 6-1. CRS-311 Front Panel

The user can fully control and monitor the operation of the CRS-311 from the front panel (shown in **Figure 6-1**), using the keypad and display. Nested menus are used, which display all available options, and prompt the user to carry out a required action.

6.1.1 Front Panel LED Indicators

6.1.1.1 Switch Status LED Indicators



The three LEDs positioned at the top left of the front panel reflect the condition of the Switch itself. The function of these LEDs is as follows:


| LED | Color | Condition |
|--------------|---------------------------|--|
| UNIT STATUS | Red | A Switch Fault exists. Example: PSU fault or COMMS failure |
| | Green | No Switch Faults |
| STORED EVENT | Off | No Stored Events |
| | Orange | Stored Events exist for the Switch. |
| | Orange (Flashing) | CAUTION: Switch is in Manual mode. |
| | Orange (Flashing 2X rate) | CAUTION: Switch is in Independent Mode. |
| REMOTE | Off | Switch is in Local Mode. Remote monitoring is possible, remote configuration control is not allowed. |
| | Orange | Switch is in Remote Mode. Configuration changes are disabled via the front panel keypad |

6.1.1.2 Modem Online Status LED Indicators



The two LEDs positioned at the lower center of the front panel reflect the online status of the Traffic or Redundant modems.

6.1.2 Front Panel Keypad



The keypad on the front panel contains six individual key switches with a positive “click” action for tactile feedback.

The function of these keys, and their reference throughout this chapter, is as follows:

| Key | Mnemonic | Functional Description |
|---|------------------------------|--|
|  | ENTER | This key is used to select a displayed function or to execute a modem configuration change. |
|  | CLEAR | This key is used to back out of a selection or to cancel a configuration change which has not been executed using ENTER . Pressing CLEAR generally returns the display to the previous selection. |
|  | ◀ ▶ (Left, Right) | These arrows are used to move to the next selection or to move the cursor position. Space permitting, most of the menus include arrow key hints to guide the user. |
|  | ▲ ▼ (Up, Down) | These arrows are used primarily to change configuration data (numbers), at the current cursor position. Occasionally they may be used to scroll through a number of choices at the current cursor position. Space permitting, most of the menus include arrow key hints to guide the user. |



The keypad has an auto-repeat feature. If a key is held down for more than 1 second, the key action will repeat, automatically, at the rate of 15 keystrokes per second. This is particularly useful when editing numeric fields, with many digits, such as frequency or data rate.

6.1.3 Front Panel Vacuum Fluorescent Display (VFD)




This screen is displayed whenever power is first applied to the unit. The display has two lines each of 24 characters. The second line identifies the modem for which the CRS-311 is configured (e.g., SLM-5650, CDM-Qx, etc.), and the CRS-311's installed firmware version.

Press any key to go to the top-level Select menu.


On most menu screens, users will see a flashing, solid-block cursor. This indicates the currently selected item, digit, or field:



Where this solid block cursor would obscure the item being edited (for example, a numeric field), the cursor will automatically change to an underline cursor:



To prevent the display from becoming burnt by a constant image, the unit employs a screen saver feature, which activates after one hour and constantly scrolls a message across the screen. The top line of the display shows the Switch ID (which can be entered by the user); the bottom line shows the current status of the Switch followed by the message 'Press any key...' as shown:



Press any key to restore the previous screen.

6.2 CRS-311 Menu Structure

Figure 6-2 shows the menu structure of the CRS-311. The screens and menus are described individually in the chapter sections that follow.




Figure 6-2. CRS-311 Menu Tree

6.3 Main Select Menu

```
SELECT:  CONFIG  INFO
MONITOR  STORE/LD  UTIL
```

Move the cursor to the desired choice using the ◀ ▶ arrow keys, then press **ENTER**.

| Branch Selection (Sect.) | Description |
|--------------------------------|--|
| CONFIG (Sect. 6.4) | (Configuration) This menu branch permits the user to fully configure the Switch. |
| INFO (Sect. 6.5) | (Information) This menu branch permits the user to view information on the Switch, without having to go into configuration screens. |
| MONITOR (Sect. 6.6) | This menu branch permits the user to monitor the status of the Switch and view the log of stored events for both the Switch and its attached modems. |
| STORE/LD (Sect. 6.7) | (Store/Load) This menu branch permits the user to store and to retrieve up to 10 different Switch configurations. |
| UTIL (Sect. 6.8) | (Utility) This menu branch permits the user to perform miscellaneous functions, such as setting the Real-time clock, adjusting the display brightness, etc. |

6.4 CONFIG (Configuration)

```
CONFIG:  MANUAL  AUTO[OFF]
        HOLDOFFS  MASKS  REMOTE
```

Move the cursor to the desired choice using the ◀ ▶ arrow keys, then press **ENTER**.

The available submenus are:

| Submenu Selection (Sect.) | Function |
|---|---|
| MANUAL (Sect. 6.4.1) | This submenu permits the user to select which Traffic Modem the Switch should bridge or backup. |
| AUTO [ON / OFF] (Sect. 6.4.2) | This submenu permits the user to turn AUTO mode to OFF or ON . The currently selected state is always shown on this menu |
| HOLDOFFS (Sect. 6.4.3) | This submenu permits the user to set several operating parameters of the Switch that pertain to enabling or disabling the availability of Traffic Modems, the reporting of faults and time delays for responding to faults. |
| MASKS (Sect. 6.4.4) | This submenu permits the user to set several operating parameters of the Switch that pertain to enabling or disabling the availability of Traffic Modems, the reporting of faults and time delays for responding to faults. |
| REMOTE (Sect. 6.4.5) | This submenu permits the user to define the remote control settings. |



The Switch may be monitored over the remote control bus at any time. When in Local mode, however, configuration parameters may only be changed through the front panel. Conversely, when in Remote mode, the unit may be monitored from the front panel, but configuration parameters via may only be changed remote control bus.

6.4.1 (CONFIG:) MANUAL

```
ONLINE :  
TRAFFIC REDUNDANT (ENT)
```

When the Switch is in Manual mode (**AUTO** is **OFF**), the user may select which modem is to be online. Use the ◀ ▶ arrow keys to select between **Traffic** Modem as online (i.e. bridging) or the **Redundant** Modem as online (ie backing up). Press **ENTER** to configure.

When in **AUTO** mode, the Switch has control, and will automatically backup the Traffic Modem, based on its fault relay activity.

In this case, the **MANUAL SELECT** screen would appear as shown:

```
ONLINE : (AUTO)  
TRAFFIC REDUNDANT (ENT)
```

In **AUTO** mode, manual selection is not available.

The Switch learns and retains the configuration of the **Traffic** Modem. This configuration information is used to program the **Redundant** Modem.

6.4.2 (CONFIG:) AUTO [OFF or ON]

```
OPERATING MODE :  
AUTO-OFF AUTO-ON (ENTER)
```

Select **AUTO-OFF** or **AUTO-ON**. When **AUTO-OFF** (manual mode) is selected, the Switch does not respond automatically to any modem faults and simply performs whatever manual setting the user performs via the **MANUAL SELECT** previous menu.

The **STORED EVENT** indicator blinks when in **AUTO-OFF** (manual) mode to alert the user that the Switch is effectively not in use.

6.4.3 (CONFIG:) HOLDOFFS

```
BACKUP HOLDOFF SEC: 05  
RESTORE HOLDOFF SEC: 10
```

Set the holdoffs, or delay times, between the Switch's modem alarm detection and its reaction to the event. These holdoffs are only applicable when the Switch is in Auto mode. When an active modem exhibits an unmasked fault, the Switch checks that the Redundant Modem is not also faulted. If there is no fault, the **Backup Holdoff** determines how long the Switch will wait before performing the actual backup, or switchover of traffic to the Redundant Modem.

When the Switch is currently backing up a Traffic Modem, and that offline modem's fault clears, the Switch will continue to back it up unless the active modem becomes faulted. In this case, the **Restore Holdoff** is the length of time that the originally faulted modem must stay unfaulted before the Switch will automatically put it back online. Both holdoffs can be set from 1 to 99 seconds.

6.4.4 (CONFIG:) MASKS

```
ALARM MASK:  MODEM-ALARMS
SW-ALARMS  AUDIO  (ENTER)
```

The Switch logs and reacts to both its own faults and modem faults. Either type of faults may be masked using this submenu. In addition, an audible buzzer can be enabled as an additional indicator.

6.4.4.1 (CONFIG: MASKS) → MODEM ALARM MASK

```
MODEM ALARM MASK:  NONE
TX  RX              (ENTER)
```

Select **TX** or **RX** to mask the pertinent traffic faults from being reacted to by the Switch. This not only prevents the Switch from performing Auto mode functions when these modem faults are sensed, but also keeps the faults from being logged by the Switch.

Note that these selections are global to all the modems. If masking of individual modem faults is desired, it should be done directly on the modem. Unmasked modem faults are logged on active modems only.

6.4.4.2 (CONFIG: MASKS) → SWITCH ALARM MASK

```
SWITCH ALARM MASK: NONE
↵PSU-A  ↵PSU-B  (ENTER)
```

Select which, if either, of the plug-in power supply units should be ignored in case any of their voltage outputs are monitored by the Switch as being out of range, then press **ENTER**.

Only one of the units can be masked at a time. Normally this would be done if the user wishes to run with only one supply, or if a bad supply had been removed for service or replacement.

6.4.4.3 (CONFIG: MASKS) → AUDIO MASK

```
AUDIO MASK:  NONE  SW-ALMS
MODEM-ALMS  BOTH  (ENT)
```

For all Switch or modem alarms that are unmasked, the user may select which alarm types should force the Switch to react with an audible buzzer located behind the front panel. In addition, a relay closure to ground activates on pin 20 of the System Alarms connector so that the user may attach other indicators.

6.4.5 (CONFIG:) REMOTE

```
SELECT REMOTE CONTROL:
LOCAL REMOTE (PRESS ENT)
```

Select **LOCAL** or **REMOTE** using the ◀ ▶ arrow keys, then press **ENTER**.

6.4.5.1 (CONFIG: REMOTE) → LOCAL

If **LOCAL** is selected, remote control will be disabled. Remote monitoring is always possible.

6.4.5.2 (CONFIG: REMOTE) → REMOTE

```
REMOTE CONTROL: BAUDRATE
INTERFACE  FORMAT  (ENT)
```

When **REMOTE** is selected, select **BAUDRATE**, **INTERFACE**, or **FORMAT** using the ◀ ▶ arrow keys, then press **ENTER**.

6.4.5.2.1 (CONFIG: REMOTE → REMOTE) BAUDRATE

```
EDIT SWITCH BAUDRATE:
9600 BAUD  (PRESS ENT)
```

Select **BAUD RATE** to select the baud rate of the remote control bus, connected locally to the M&C computer.

Values of 300, 1200, 2400, 4800, 9600 and 19200 baud are possible. Change the value using the ▲ ▼ arrow keys, then press **ENTER**.

Note: This setting does not affect the internal communications between the Switch and the modems. For the SLM-5650, this is fixed at RS-232, 9600 baud, 8-N-1.

6.4.5.2.2 (CONFIG: REMOTE → REMOTE) INTERFACE

```
ELECT. INTERFACE:  RS232
RS485-2W   RS485-4W (ENT)
```

Select **INTERFACE** to select **RS-232**, **RS485-2W** (2-wire), or **RS485-4W** (4-wire) using the ◀ ▶ arrow keys. Press **ENTER** to enter the bus address.

```
IN RS232 MODE THE BUS
ADDRESS IS FIXED AT 0000
```

In the above screen, RS-232 mode is used and the bus address is fixed at 0.

```
EDIT SWITCH BUS ADDRESS:
3000      (PRESS ENTER)
```

If in RS-485 mode, the address may be selected. Change the value of the address using the ▲ ▼ arrow keys, then press **ENTER**.

The valid addresses are 1000, 3000, 5000 and 7000 only, as explained in the Remote section of this manual.

6.4.5.2.3 (CONFIG: REMOTE → REMOTE) FORMAT

```
SELECT DATA FORMAT:
8-N-1   7-E-2   7-O-2
```

Note: This setting does not affect the internal communications between the Switch and the modems. For the SLM-5650, this is fixed at RS-232, 9600 baud, 8-N-1.

6.5 INFO (INFORMATION)

```
INFO:  S/N   ID   SETUP
IF-SWITCH  REMCONT  MASK
```

Select **S/N**, **ID**, **SETUP**, **IF-SWITCH**, **REMCNT**, or **MASK** using the ◀ ▶ arrow keys, then press **ENTER**. These screens display information on the current configuration of the Switch without risking inadvertent alterations.

6.5.1 (INFO:) S/N

```
Serial Number:  
XXXXXXXXXX (CLEAR)
```

The nine-digit serial number unique to this CRS-311 unit is displayed. Press **CLEAR** to return to the previous menu.

6.5.2 (INFO:) ID

```
SWITCH ID:  
-----
```

The user-defined Switch ID string is displayed, which is entered via the **UTILITY: SW-ID** screen. Press **ENTER** or **CLEAR** to return to the previous menu.

6.5.3 (INFO:) SETUP

```
TRAFFIC MODEM IS ONLINE.  
AUTO:OFF BKUP:05 REST:04
```

The information on this screen reflects some of the settings as defined in the **CONFIG:** submenus. The online modem is listed on the top line, with Auto mode and the two holdoff times listed on the bottom. Press **ENTER** or **CLEAR** to return to the previous menu.

6.5.4 (INFO) IF-SWITCH

```
TRANSPONDER SWITCH IS  
PRESENT
```

The presence of the CRS-281 IF Transponder Switch is displayed. Press **ENTER** or **CLEAR** to return to the previous menu.

6.5.5 (INFO:) REMCONT (Remote Control Info)

```
REM CNTL: ON RS232  
ADDR:0000 9600 BAUD 8N1
```

This screen shows if the unit is in **LOCAL** or **REMOTE** mode, and gives details of the electrical interface type, the unit address, the baud rate, and data format. Press **ENTER** or **CLEAR** to return to the previous menu.

6.5.6 (INFO:) MASK (Alarms Masked Info)

```
ALARMS MASKED:  MODEM-TX  
MODEM-RX  ↵PSU-A  ↵PSU-B
```

This screen shows the alarms that are currently masked. If an alarm is not masked, a blank is displayed in the relevant screen position. Power Supplies A and B cannot be both masked at the same time, but are shown together here to indicate their relative positions on the screen. Press **ENTER** or **CLEAR** to return to the previous menu.

6.6 MONITOR

```
MONITOR:  STATUS  SW-ALARM  
STORED-EVENTS  COMMS  IO
```

Select **STATUS**, **SW-ALARM**, **STORED-EVENTS**, **COMMs** (COMM-STATE), or **IO** using the ◀ ▶ arrow keys, then press **ENTER**.

6.6.1 (MONITOR:) STATUS

```
TRAFFIC MODEM IS ONLINE.  
BACKUP HOLDOFF: 05 SEC
```

The status of the Switch is displayed.

If Auto mode is on, it will also show the backup holdoff-time should the bridged TM fail. If Auto mode is off, the second line displays “**OFF**”. When the Switch has taken the TM offline and replaced it with the RM (whether done manually or automatically), the screen changes as shown:

```
REDUNDANT IS ONLINE.  
RESTORE HOLDOFF: 05 SEC
```

The restore holdoff time is shown on the second line if Auto mode is “**ON**”.

6.6.2 (MONITOR:) SW-ALARM

```
SWITCH ALARM:  NONE
```

The above screen shows another example of a Switch’s fault status. In this example, *there are no faults*; accordingly, the front panel LED “**Unit Status**” should be **GREEN**.

```
SWITCH ALARM:  -12V PS-B  
                ↙ IS UNDERVOLTAGE
```

The above screen shows another example of a Switch's fault status. In this example, *there is a fault* – Power supply “B” is under voltage; accordingly, the front panel LED “Unit Status” will be **RED**.

Suggested corrective actions include:

- Ensure power supply power cord is connected and the power switch is **ON**;
- Replace defective power supply module;
- If the second power supply module is not needed, the user can mask this Alarm.

```
SWITCH ALARM:  RM PROBLEM  
                RM I/O TIMEOUT
```

-OR-

```
SWITCH ALARM:  MODEM COMMS  
                PROBLEM, TRAFFIC MODEM
```

The above screens shows additional examples of a Switch's fault status. In these examples, *there are faults* – communication has been lost to the Redundant or the Traffic Modem; accordingly, the front panel LED “Unit Status” will be **RED**.

Suggested corrective actions include:

- **Check cable connections.** Refer to **Chapter 3. CABLES AND CONNECTIONS**.
- **Check cable operation.** Ensure the cables are OK by swapping them with others. For cable information refer to **Chapter 3. CABLES AND CONNECTIONS** and **Appendix A. CABLE DRAWINGS**.
- **Check modem configurations.** Refer to **Chapter 4. MODEM AND SWITCH CONFIGURATION** and the pertinent modem's *Installation and Operation Manual*.

```
SWITCH ALARM:  RM PROBLEM  
                MGC refused, cpde: 12 TFT
```

The above screen shows another example of a Switch's fault status. In this example, *there is a fault*. COMMs are good to the Redundant Modem, but the configuration of the Traffic Modem cannot be configured into the Redundant Modem. The front panel LED “Unit Status” will be **RED**.

Suggested corrective actions include:

- Ensure the most capable modem is used as the Redundant Modem, with regard to FAST options, installed options, e.g. Turbo card, firmware version, and hardware revision. The code indicates the parameter within the MGC configuration string that is causing the Redundant Modem to refuse it. The three-letter instruction code is indicated also to assist decoding the problem parameter:

- **For the CDM-Qx modem**, the code is the decimal number indicating the problem parameter within its MGC configuration code:

| | | | | |
|----|--------------------------------|----|-----|--------------------------|
| 00 | NO ERROR | 01 | ITF | Interface |
| 02 | LBO T1 Line Build-Out | 03 | FRM | Framing mode |
| 04 | TFQ Tx Frequency | 05 | TFT | Tx FEC Type |
| 06 | TMD Tx Modulation | 07 | TCR | Tx FEC Code Rate |
| 08 | TDR Tx Data Rate | 09 | TSI | Tx Spectrum Invert |
| 10 | TSC Tx Scrambler state | 11 | TPL | Tx Power Level |
| 12 | TCK Tx Clock | 13 | TDI | Tx Data Invert |
| 14 | TXO Tx Carrier State | 15 | AUP | AUPC enable |
| 16 | APP AUPC parameters | 17 | WUD | Warm-Up Delay |
| 18 | TXC Tx common output state | 19 | TRS | Tx Reed-Solomon |
| 20 | TXA Tx roll-off (alpha) factor | 21 | TCI | Tx Data Clock Invert |
| 22 | RFQ Rx Frequency | 23 | RFT | Rx FEC Type |
| 24 | RMD Rx Modulation | 25 | RCR | Rx FEC Code Rate |
| 26 | RDR Rx Data Rate | 27 | RSI | Rx Spectrum Invert |
| 28 | RDS Rx DeScrambler state | 29 | RDI | Rx Data Invert |
| 30 | RSW Rx Sweep Width | 31 | EBA | Eb/No Alarm point |
| 32 | BCS Rx Buffer clock source | 33 | RRS | Rx Reed-Solomon |
| 34 | RBS Rx Buffer size/enable | 35 | RCI | Rx Data Clock Invert |
| 36 | ERF External Reference setting | 37 | EFM | EDMAC Framing mode |
| 38 | ESA EDMAC Slave Address range | 39 | TST | Test mode (read-only) |
| 40 | MSK Alarm Masks | 41 | RTS | Request-To-Send control |
| 42 | SSI Statistics Sample Interval | 43 | CNM | CnC Mode |
| 44 | CFO CnC Frequency Offset | 45 | CSD | CnC Min/Max Search Delay |
| 46 | CRA CnC Re-acquisition Time | | | |

6.6.3 (MONITOR:) STORED EVENTS

```

STORED EVENTS:    VIEW
CLEAR-ALL (PRESS ENTER)
    
```

Select **VIEW** or **CLEAR-ALL** using the ◀ ▶ arrow keys, then press **ENTER**.

If **CLEAR-ALL** is selected, the event log is cleared and the user is taken directly back to the previous menu. However, if there are faults present on the unit at this time, new log entries will be generated for those faults.

Note that, in accordance with international convention, the date is shown in **DAY-MONTH-YEAR** format.

6.6.3.1 (MONITOR: STORED-EVENTS) → VIEW

```
LOG23: 26/01/00 10:37:32  
FT-06 RX ALARM (UP/DN)
```

The user may scroll backwards or forwards through the entries in the event log, using the ▲ ▼ arrow keys. Press **ENTER** or **CLEAR** to return to the previous menu.

The event log can store up to 98 events. When a fault (FT) condition occurs, it is time-stamped and put into the log. Similarly, when the fault condition clears (OK), this is also recorded, as shown:

```
LOG24: 26/01/04 10:37:35  
OK-06 RX ALARM (UP/DN)
```

Next to the **FT/OK** indicator is a code for the faulted unit: the **TM**, (for Traffic Modem), **RM** (for Redundant Modem) or **SW** (for the Switch).

6.6.4 (MONITOR:) COMMS (Communications State)

```
COMMS:          TRAFFIC: OK  
              REDUNDANT: FT
```

The above screen indicates that the Switch has good or bad monitoring I/O communications with the modems. This does not indicate fault status.

6.6.5 (MONITOR:) IO

```
T <0000/LRS ?  
>0000/LRS=1
```

The above screen shows actual communication strings between the Switch and the modems. When in this mode, the communication is slowed down to enable viewing of messages. Because of this, it should only be used for troubleshooting purposes.

- **Upper line:** Switch controller's outbound messages
- **Lower line:** Modem responses
- **First character:** Indicates the device being addressed (**T** = Traffic Modem; **R** = Redundant Modem).

6.7 STORE/LD (Store or Load Configuration)

```
STORE/LOAD CONFIG:
STORE  LOAD  (PRESS ENTER)
```

Select **STORE** or **LOAD** using the ◀ ▶ arrow keys, then to press **ENTER**.

These submenus permit the user to store or load up to 10 different Switch configurations in its non-volatile memory. These are configurations for the Switch itself, not the modems to which attached to it.



This feature is operational in LOCAL MODE ONLY. If the User attempts to save or load a configuration while in Remote Mode, the following message displays:

```
THE SWITCH IS CURRENTLY
IN REMOTE MODE!! (CLEAR)
```

6.7.1 (STORE/LD) STORE

```
STORE CONFIGURATION TO
LOCATION: 10  (ENTER)
```

Select the location to store the current configuration to, using the ▲ ▼ arrow keys, then press **ENTER**. Locations 1 through 10 are available.

If the selected location does not contain a previously stored configuration, the following screen is displayed:

```
YOUR CONFIGURATION HAS
BEEN STORED!  (ENTER)
```

Press **ENTER** or **CLEAR** to return to the previous menu. If, however, the selected location contains a previously stored configuration, the following screen is displayed:

```
WARNING!  LOC 10 CONTAINS
DATA!  OVERWRITE?  NO  YES
```

Select **NO** or **YES** using the ◀ ▶ arrow keys, then press **ENTER**. Selecting **YES** will overwrite the existing configuration at the selected location.

6.7.2 (STORE/LD) LOAD

```
LOAD CONFIGURATION FROM  
LOCATION: 10 (ENTER)
```

Select the location from which to load a configuration using the ▲ ▼ arrow keys, then press **ENTER**. Locations 1 through 10 are available. If the selected location contains valid data, the following screen is displayed:

```
THE NEW CONFIGURATION  
HAS BEEN LOADED (ENTER)
```

Press **ENTER** or **CLEAR** to return to the previous menu. If, however, the selected location does not contain valid data, the following screen is displayed:

```
WARNING! LOC 10 CONTAINS  
NO DATA! (ENTER)
```

Press **ENTER** or **CLEAR** to return to the previous menu.

6.8 UTILITY

This submenu permits the user to select from a number of different utility functions, which are described in the following sections.

```
UTILITY: SET-RTC DISPLAY  
SW-ID TYPE INDEP-MODE
```

Select **SET-RTC**, **DISPLAY**, **SW-ID**, or **INDEP-MODE** using the ◀ ▶ arrow keys, then press **ENTER**.



While TYPE is selectable on this menu, it is intended for CEFD internal (factory) test / diagnostic use only and provides no functional purpose to the User.

6.8.1 (UTILITY:) SET-RTC (Set Real-Time Clock)

```
EDIT REAL TIME CLOCK:  
12:00:00 24/04/00 (ENT)
```

Edit the time and date settings of the real-time clock by selecting the digit to be edited using the ◀ ▶ arrow keys; the value of the digit is then changed using the ▲ ▼ arrow keys.

Note that, in accordance with international convention, the date is shown in **DAY-MONTH-YEAR** format. The user should then press **ENTER**.

6.8.2 (UTILITY:) DISPLAY (Display Brightness)

```
EDIT DISPLAY BRIGHTNESS:  
100%          (PRESS ENTER)
```

Brightness levels of 25%, 50%, 75% or 100% are selectable. Edit the display brightness using the ▲▼ arrow keys. Once the desired brightness has been set, press **ENTER**.

6.8.3 (UTILITY:) SW-ID (Switch ID)

```
EDIT SWITCH ID:  (ENTER)  
---- THIS IS A TEST ----
```

Edit the Switch ID string using the ▲ ▼ and ◀ ▶ arrow keys. Only the bottom line is available (24 characters). The cursor selects the position on the bottom line (◀ ▶ arrow keys) and the character is then edited (▲ ▼ arrow keys).

The following characters are available:

[Space] () * + - , . / 0-9 and A-Z.

When finishing composing the string, press **ENTER**.

6.8.4 (UTILITY:) INDEP-MODE (Independent Mode)



*This feature is for use **ONLY** with the SLM-5650/5650A.*

```
INDEPENDENT MODE:  
NORMAL-OP  ENABLE-INDEP
```

In Independent Mode, the modems each operate independently and simultaneously (dual-carrier). In this mode, the CRS-311 is used only to enable control and monitoring of both modems via a single RS-232/RS-485 control line.

Use the ◀ ▶ arrow keys to select between **NORMAL-OP** (*NORMAL-OPerations*) and **ENABLE-INDEP** (*ENABLE INDEPendent Mode*). Press **ENTER** to configure.

Appendix A. CABLE DRAWINGS

A.1 Introduction

This appendix contains drawings of cables used with the CRS-311. These cables are broken into three categories: User / Utility Cables, Control Cables, and Data Cables. Each section provides illustrations of the cables' technical specifications; additionally, the tables featured in Control and Data Cable sections cross-reference to the illustrations found in **Chapter 3. CABLES AND CONNECTIONS**.

A.2 User / Utility Cables

| App. A FIG | REF Ch. 3 FIG | CEFD CABLE P/N | DESCRIPTION | USED WITH CRS-311 → ... | USED FOR (DATA TYPE) |
|------------|---------------|----------------|-------------|--|------------------------------------|
| A-1 | N/A | N/A | N/A | User data | RS-530 → RS-422/449 DCE Conversion |
| A-2 | N/A | N/A | N/A | User data | RS-530 → V.35 DCE Conversion |
| A-3 | N/A | N/A | N/A | User RS-232 Switch Programming / Flash Upgrade | CRS-311 Remote → PC Serial Port |

A.2.1 RS-530 to RS-422 Data Cable

Figure A-1 shows the cable drawing for RS-530 to RS-422/449 DCE conversion for connections between the Switch and the User data.




Figure A-1. DCE Conversion Cable: RS-530 to RS-422/449

A.2.2 RS-530 to V.35 Data Cable

Figure A-2 shows the cable drawing for RS-530 to V.35 DCE conversion for connections between the Switch and the User data.




Figure A-2. DCE Conversion Cable: RS-530 to V.35

A.2.3 Switch Programming Cable

Figure A-3 shows the cable required for a simple RS-232 connection between the CRS-311 remote control port and a PC serial port. This cable is needed for Flash upgrading.




Figure A-3. Switch Programming Cable

A.3 Control Cables

| App. A FIG | REF Ch. 3 FIG | CEFD CABLE P/N | DESCRIPTION | USED WITH CRS-311 → | USED FOR (TYPE) |
|------------|---------------------------------|----------------|----------------------------|---|---------------------------------------|
| A-4 | 3-1 | CA-0000095 | (6X) DB-9F Ribbon | CDM-Qx/QxL | RS-485 Multi-drop (<i>optional</i>) |
| A-5 | 3-1 | CA-0000096 | (6X) DB-9F Shielded | | RS-485 Multi-drop (<i>standard</i>) |
| A-6 | 3-1 | CA/WR11418-1 | Terminal | | Terminal |
| A-7 | 3-1 | CA/WR11419-1 | DB-9M → DB-9M, 6" | | Null Modem |
| A-8 | 3-2 3-3 3-4 3-5 3-6 | CA-0000009 | HD-15M → (2X) DB-15F, 4' | | Control 'Y' |
| A-9 | 3-9 3-10 | CA/WR12136-2 | HD-15M → HD-15M, 4' | SLM-5650/5650A | Control |
| A-10 | 3-13 | CA-0000006 | DB-50M → (2X) DB-25F, 4' | (CRS-351) → SLM-5650/5650A | Control 'Y' |
| A-11 | N/A | CA/WR12842-4 | HD-15M → DB-9M, HD-15M, 4' | TMI/RMI → SLM-5650/5650A Overhead → User | Control 'Y' |

A.3.1 Optional RS-485 Multi-drop Ribbon Cable, (6X) DB-9 Female

Figure A-4 shows the optional RS-485 Multi-drop Ribbon Cable. This cable is required to daisy-chain the CDM-Qx/QxL modems and Switch together for communications. If Electromagnetic Compatibility (EMC) is a concern, then use the standard RS-485 Multi-Drop Shielded Cable.




Figure A-4. Optional RS-485 Multi-Drop Ribbon Cable (CA-000095)

A.3.2 Standard RS-485 Multi-drop Shielded Cable, (6X) DB-9 Female

Figure A-5 shows the standard RS-485 Multi-drop Shielded Cable. This cable is required to daisy-chain the CDM-Qx/QxL modems and Switch together for communications. If Electromagnetic Compatibility (EMC) is not a concern, then use the optional RS-485 Multi-drop Ribbon Cable.




Figure A-5. Standard RS-485 Multi-Drop Shielded Cable (CA-000096)

A.3.3 RS-485 Cable Termination, (15X) DB-9 Male

Figure A-6 shows the RS-485 Cable Termination required for terminating the ends of the optional RS-485 Multi-Drop Ribbon Cable (CA-0000095) or standard RS-485 Multi-Drop Shielded Cable (CA-0000096).




Figure A-6. RS-485 Cable Termination (CA/WR11418-1)

A.3.4 RS-485 Null Modem Cable, DB-9 Male

Figure A-7 shows the RS-485 Null Modem Cable required for the RS-485 multi-drop for the CDM-Qx/QxL modems. This attaches to the DB-9F “485 Pass-through” connector on the CRS-230 controller module.




Figure A-7. RS-485 Null Modem Cable (CA/WR11419-1)

A.3.5 Control 'Y' Cable for CDM-Qx and CDM-QxL with CnC®

Figure A-8 shows one of the two types of control cables required for the CDM-Qx/QxL modems. This cable adapts from both mod and demod DB-15 Alarm connectors on the modem to a HD-15 Fault connector on the Switch TMI/RMI. These interfaces are capable of CnC® support.




Figure A-8. Control 'Y' Cable for CDM-QxL with CnC® (CA-000009)

A.3.6 Control Cable for SLM-5650/5650A

Figure A-9 shows the control cable that connects the SLM-5650/5650A to the CRS-311.




Figure A-9. SLM-5650/5650A Control Cable (CA/WR12136-2)

A.3.7 Control 'Y' Overhead Cable for CRS-351 → SLM-5650/5650A

Figure A-10 shows the control cable that connects the SLM-5650/5650A Redundant and Traffic “P1 Overhead Data” ports to the CRS-351 Overhead Module on the CRS-311. This cable is used where protection of the overhead signals (backward alarms, audio ESC, data ESC, etc.) is desired.




Figure A-10. SLM-5650/5650A Control 'Y' Overhead Cable (CA-000006)

A.3.8 Control 'Y' Cable for SLM-5650/5650A to CRS-311

Figure A-11 shows the Control 'Y' Cable that connects the SLM-5650/5650A to the CRS-311 RMI/TMI. This is an optional cable, purchased separately, used in place of the CA/WR12136-2 cable (see Figure A-9) to give the User access to the AGC and I&Q outputs of the modem.




Figure A-11. SLM-5650/5650A Control 'Y' Cable (CA/WR12842-4)

A.4 Data Cables

| App. A FIG | REF Ch. 4 FIG | CEFD CABLE P/N | DESCRIPTION | USED WITH CRS-311 → ... [(CRS-XXX) denotes installed module] | USED FOR (TYPE) |
|------------|--------------------|----------------|-------------------------|---|--|
| A-12 | 3-2 3-11 | CA/WR0066-4 | DB-25M → DB-25F, 4' | CDM-Qx/QxL (CRS-351) → SLM-5650/5650A | RS-422 Data " " , EIA-530/RS-232 |
| A-13 | 3-3 3-10 | CA/WR9038-4 | DB-15M → DB-15F, 4' | CDM-Qx/QxL SLM-5650/5650A | Bal G.703 Data |
| A-14 | 3-4 3-7 3-10 | PL/0813-4 | 75Ω BNC → 75Ω BNC, 4' | CDM-Qx/QxL (CRS-281) → CDM-Qx SLM-5650/5650A | Unbal G.703 Data IF Unbal G.703 Data |
| A-15 | 3-5 3-9 | CA/WR9189-4 | HD-50M → HD-50M, 4' | CDM-Qx/QxL SLM-5650/5650A | HSSI Data |
| A-16 | 3-6 | CA/WR13018-2 | DB-15F → (4X) RJ45, 6' | CDM-Qx/QxL | Quad E1 Data |
| A-17 | 3-6 3-9 3-12 | PP/CAT5FF3FTGY | RJ45 → RJ45, 3' | CDM-Qx/QxL SLM-5650/5650A | Quad E1 Data Cat5 Ethernet |
| A-18 | 3-7 | PL/0946-1 | 50Ω BNC → 50Ω BNC, 4' | (CRS-281) → CDM-Qx | IF |
| A-19 | 3-8 3-15 | CA/RF10453-4 | Type 'N' → Type 'N', 4' | (CRS-281A) → CDM-QxL (CRS-281L) → SLM-5650/5650A | IF |
| A-20 | 3-14 | CA/3005-1 | 50Ω TNC → 50Ω TNC, 4' | (CRS-281) → SLM-5650/5650A | IF |

A.4.1 RS-232/422, EIA-530 Control and Data Cable, DB-25

Figure A-12 shows the RS-232/422, EIA-530 Data cable for connection between the Switch and Modem or between the Switch and the User data.

| INDICATORS | | |
|------------|-------|-----|
| 25M | NOTES | 25F |
| 1 | TO | 1 |
| 2 | TO | 2 |
| 3 | TO | 3 |
| 4 | TO | 4 |
| 5 | TO | 5 |
| 6 | TO | 6 |
| 7 | TO | 7 |
| 8 | TO | 8 |
| 9 | TO | 9 |
| 10 | TO | 10 |
| 11 | TO | 11 |
| 12 | TO | 12 |
| 13 | TO | 13 |
| 14 | TO | 14 |
| 15 | TO | 15 |
| 16 | TO | 16 |
| 17 | TO | 17 |
| 18 | TO | 18 |
| 19 | TO | 19 |
| 20 | TO | 20 |
| 21 | TO | 21 |
| 22 | TO | 22 |
| 23 | TO | 23 |
| 24 | TO | 24 |
| 25 | TO | 25 |




Figure A-12. RS-232/422, EIA-530 Control and Data Cable (CA/WR0066-4)

A.4.2 Balanced G.703 Data Cable, DB-15

Figure A-13 shows the Balanced G.703 Data cable for connection between the Switch and Modem or between the Switch and the User data.

| INDICATORS | | |
|------------|-------|-----|
| 15M | NOTES | 15M |
| 1 | TO | 1 |
| 2 | TO | 2 |
| 3 | TO | 3 |
| 4 | TO | 4 |
| 5 | TO | 5 |
| 6 | TO | 6 |
| 7 | TO | 7 |
| 9 | TO | 9 |
| 11 | TO | 11 |
| 12 | TO | 12 |
| 13 | TO | 13 |
| 15 | TO | 15 |




Figure A-13. Balanced G.703 Data Cable (CA/WR9038-4)

A.4.3 Balanced G.703 / IF Cable, BNC, 75Ω

Figure A-14 shows the 75Ω BNC cable used for the Balanced G.703 data connections between the CRS-311 and Modem. It is also used for connecting the Modem to the CRS-281 (70/140 MHz) IF Switch.




Figure A-14. Balanced G.703 / IF Cable, BNC 75Ω (PL/0813-4)

A.4.4 HSSI Data Cable

Figure A-15 shows the HSSI data cable used for connections between the Switch and the Modem.




Figure A-15. HSSI Data Cable (CA/WR9189-4)

A.4.5 Quad E1 Data Cable for CDM-Qx/QxL

Figure A-16 shows the cable used to connect the Switch RMI (CRS-305) to the redundant CDM-Qx/QxL Quad E1 interface.





Figure A-16. CDM-Qx/QxL Quad E1 Data Cable (CA/WR13018-2)

A.4.6 Quad E1 / Gigabit Ethernet Connector Cable

Figure A-17 shows the cable used for the CDM-Qx/QxL Quad E1 data connections, and Gigabit Ethernet connections for the SLM-5650/5650A modems.



| T568B Wiring Diagram | | |
|----------------------|---------------------|---------|
| Pair No. | Wire | Pin No. |
| 1 | Blue/White tracer | 5 |
| | Blue | 4 |
| 2 | Orange/White tracer | 1 |
| | Orange | 2 |
| 3 | Green/White tracer | 3 |
| | Green | 6 |
| 4 | Brown/White tracer | 7 |
| | Brown | 8 |

350 MHz Category 5E Patch Cable Specs:

- EIA/TIA TSB-40A ETL Verified
- Contact Gold Plating 50μ" (Short body)
- Assembly Strain Relief
- Stranded 50dB
- RoHS Compliant
- Length: 3 ft.

Figure A-17. Quad E1 / GigE Connector Cable (PP/CAT5FF3FTGY)

A.4.7 IF Cable, BNC, 50Ω

Figure A-18 shows the 50Ω BNC cable used for connecting the Modem to the CRS-281 (70/140 MHz) IF Switch.




Figure A-18. IF Cable, BNC 50Ω for CRS-281 (70/140 MHz) IF Switch (PL/0946-1)

A.4.8 IF Cable, Type 'N', 50Ω

Figure A-19 shows the 50Ω Type 'N' cable used for connecting the Modem to the CRS-281L and CRS-281A IF Switches.




Figure A-19. IF Cable, Type 'N' 50Ω for CRS-281A / CRS-281L (L-Band) IF Switches (CA/RF10453-4)

A.4.9 IF Cable, TNC, 50Ω

Figure A-20 shows the 50Ω TNC cable used for connecting the Modem to the CRS-281 (70/140 MHz) IF Switch.




Figure A-20. IF Cable, TNC 50Ω for CRS-281 (70/140 MHz) IF Switch (CA/3005-1)

This page is deliberately blank.

Appendix B. ADDRESSING SCHEME INFORMATION

B.1 Introduction to Addressing

A CRS-311 1:1 Redundancy Switch provides 1:1 modem redundancy; that is, it is capable of controlling one Traffic Modem and one Redundant Modem.

The user can remotely communicate to the Switch or either of the modems, using the appropriate addresses, via RS-232 or RS-485 using the DB-9M “Remote Control” connector on the CRS-230 Switch Controller card (installed in the CRS-311).

For Switch to modem communications using SLM-5650/5650A modems, the Switch uses serial communication via a the HD-15 Control Cable that is connected between each TMI/RMI and the modems.

For Switch to modem communications using CDM-Qx/QxL modems, the Switch uses RS-485 communications via a DB-9 multi-drop cable that is connected from the “485 Pass-Through” connector on the CRS-230, then daisy-chained to each of the modems.

If the modems are configured for EDMAC framing, Monitor & Control (M&C) information may be communicated to the modems and transceivers at the distant-end of the link. In order for an M&C application to be able to communicate with the various modems connected to the Switch, the correct addresses must be used.

This appendix provides details of the address requirements to allow M&C of the Switch and the various modems that may be included in a CRS-311 1:1 Redundancy Switch system.

B.2 Switch Address

The permitted Switch remote control addresses are limited:

- For **RS-485** connections, the only permitted addresses are 1000, 3000, 5000, and 7000.
- For **RS-232**, the only permitted address is 0000.

Note: The Switch settings for external communications are totally independent from the internal communication between Switch and traffic modems.

B.3 Modem and Transceiver Addresses

To monitor and control modems and transceivers at the distant-end of the communication link, EDMAC must be enabled, via the modem front panel, in local mode. Set the Tx and Rx parameters to establish the link on the modems on each end of the link. Then an M&C application can be used.

Examples of RS-232 and RS-485 addressing schemes are shown in the diagrams that follow. Included in these diagrams is the following terminology:

| Abbreviation | Explanation |
|--------------|--|
| MCA | Monitor & Control Address, to be entered as the address of a unit into an M&C application, e.g., SatMac. |
| | Modem addresses are automatically assigned by the TMI/RMI slot positions to which they are associated within a Switch. |
| | When using RS-485 multi-drop, the Switch bus address be changed on the Switch by the User to 1000, 3000, 5000, 7000, or 9000 (7000 is shown in the figures in this appendix as an example only). |
| RCA | Remote Control Address, to be configured, via the unit front panel (CONFIG:REMOTE) |
| ESA | <ul style="list-style-type: none"> • EDMAC Slave Address (Range) • Local modem is configured as EDMAC master • Distant-end modem is an EDMAC slave |

The SLM-5650/5650A modems utilize a point-to-point internal serial communications bus to the Switch within the HD-15 cable. **Figure B-1** illustrates an external RS-232 addressing scheme for these modems; **Figure B-2** depicts an external RS-485 connection.

The CDM-Qx/QxL modems require an external multi-drop RS-485 connection. **Figure B-3** illustrates the external RS-232 addressing scheme for a system comprising these modems with a Switch; **Figure B-4** depicts the external RS-485 connection for this configuration. For a distant-end CRS-300/Qx/QxL Switch using Traffic modems in EDMAC Slave mode, refer to **Figure B-5**.




Figure B-1. CRS-311 Addressing Scheme Example: External RS-232 with SLM-5650/5650A Modems




Figure B-2. CRS-311 Addressing Scheme Example: External RS-485 with SLM-5650/5650A Modems




Figure B-3. CRS-311 Addressing Scheme Example: External RS-232 with CDM-Qx/QxL Modems




Figure B-4. CRS-311 Addressing Scheme Example: External RS-485 with CDM-Qx/QxL Modems




Figure B-5. CRS-311 Addressing Scheme Example: External RS-485 with CDM-Qx/QxL Modems, EDMAC CRS-311 to CRS-311

B.3.1 Setting Up Modems (CDM-Qx/QxL only)

- **Local Traffic Modem** on Switch:
 - $MCA = (\text{Switch RCA}) + (100)$
 - Set EDMAC Framing on.
 - Set as EDMAC master.
 - Set with EDMAC Slave Address Range, $ESA = (\text{Modem RCA}) + 10$
- **Distant Modem 1** (attached to the Distant end of link to Traffic Modem):
 - Remote control address: no setting required (Remote control not used).
 - Set EDMAC Framing on.
 - Set as an EDMAC slave.
 - Set Slave Address, $ESA = (\text{Master ESA}) + 1$
 - $MCA = ESA$

- **Two Distant Modems** in a 1:1 configuration:

Set up the on-line modem as for Distant Modem 1, described previously in this section. The offline modem is automatically configured to match the on-line modem. M&C can only be achieved to the online modem.

Notes:

1. 1:1 internal redundancy in EDMAC Slave mode is available only in firmware version 1.6.2 or later.
2. It is not possible for the offline modem of a 1:1 pair to respond to EDMAC messages directly as it is not transmitting. Using the internal 1:1 link, the online modem polls and retains the off-line modem status. Depending on the modem, this information can be obtained as follows:

Use **FLT (Faults and Status) – FLT?** for queries. This command/query is available in available in firmware versions 1.6.2 or later.

Refer to the *Comtech EF Data CDM-Qx Multi-Channel Satellite Modem Installation and Operation Manual* for additional information.

B.4 M&C Application

The system is set up such that it may be communicated to by an Monitor & Control (M&C) application, e.g., SatMac or CMCS. In the SatMac application, go to the **Link Edit Mode** screen to enter the Monitor & Control Addresses (MCA).

Appendix C. REMOTE CONTROL

C.1 Introduction

This appendix describes the protocol and message command set for remote monitor and control of the CRS-311 1:1 Redundancy Switch.

The electrical interface is either an RS-485 multi-drop bus (for the control of many devices) or an RS-232 connection (for the control of a single device), and data is transmitted in asynchronous serial form, using ASCII characters. Control and status information is transmitted in packets of variable length, in accordance with the structure and protocol defined in later sections.



The Remote Control pinout is shown in Chapter 5.1.3 Remote Control – DB-9M Connector for RS-232 and RS-485.

C.2 RS-485

For applications where multiple devices are to be monitored and controlled, a full-duplex (4-wire plus ground) RS-485 is preferred. Half-duplex (2-wire plus ground) RS-485 is possible, but is not preferred. In full-duplex RS-485 communication, there are two separate, isolated, independent, differential-mode twisted pairs, each handling serial data in different directions.

It is assumed that a 'Controller' device (a PC or dumb terminal) transmits data in a broadcast mode via one of the pairs. Many 'Target' devices are connected to this pair, and all simultaneously receive data from the Controller. The Controller is the only device with a line-driver connected to this pair; the Target devices have only line-receivers connected.

In the other direction: On the other pair, each Target has a tri-state line driver connected; the Controller has a line-receiver connected. All the line drivers are held in high-impedance mode until one – and *only* one – Target transmits back to the Controller. Each Target has a unique address; each time the Controller transmits, the address of the intended recipient Target is included in a framed 'packet' of data. All of the Targets receive the packet, but only one (the intended) will reply. The Target enables its output line driver and transmits its return data packet back to the Controller in the other direction on the physically separate pair.

RS-485 (full duplex) summary:

- Two differential pairs - one pair for Controller-to-Target, one pair for Target-to-Controller.
- Controller-to-Target pair has one line driver (Controller), and all Targets have line-receivers.
- Target-to-Controller pair has one line receiver (Controller), and all Targets have tri-state drivers.

C.3 RS-232

This is a much simpler configuration in which the Controller device is connected directly to the Target via a two-wire-plus-ground connection. Controller-to-Target data is carried, via RS-232 electrical levels, on one conductor, and Target-to-Controller data is carried in the other direction on the other conductor.

C.4 Basic Protocol

Whether in RS-232 or RS-485 mode, all data is transmitted as asynchronous serial characters, suitable for transmission and reception by a UART. The asynchronous character format may be selected from 8-N-1 (8 data bits, no parity, one stop bit), 7-E-2 (7 data bits, even parity, 2 stop bits) or 7-O-2 (7 data bits, odd parity, 2 stop bits). The baud rate may vary between 300 and 19,200 baud.

All data is transmitted in framed packets. The Controller is assumed to be a PC or ASCII dumb terminal that is in charge of the process of monitor and control. The Controller is the only device that is permitted to initiate, at will, the transmission of data. Targets are only permitted to transmit when they have been specifically instructed to do so by the Controller.

All bytes within a packet are printable ASCII characters, less than ASCII code 127. In this context, the Carriage Return and Line Feed characters are considered printable.

All messages from Controller-to-Target require a response, with one exception: This will be either to return data that has been requested by the Controller, or to acknowledge reception of an instruction to change the configuration of the Target. The exception to this is when the Controller broadcasts a message (such as Set Time/Date) using Address 0, when the Target is set to RS-485 mode.

C.4.1 Rules for Remote Serial Communications with the CRS-311

1. Always wait for a response (or up to 15 seconds) from the CRS-311 before sending the next query or command.
2. If a "time-out" response ('~') is sent from the CRS-311, the User must resend the previous command.

The '~' response indicates that a pass-through command to a modem/transceiver attached to the CRS-311 has "timed-out" and there was no response from the other device. During this wait, do not communicate with the CRS-311. After the '~' response is sent by the CRS-311, it is now ready to receive a message again. The CRS-311 knows to wait different times for the different messages it is sending to modems:

- Status queries (no commands) are fast (typically less than 333 ms).
- Configuration changes (commands) take longer and vary by modem type.
- Individual command responses are faster than those to global commands (MGC). More parameters require more time.
- A pass-through command is passed with little inspection by the Switch but, remember, the modem being addressed may be at the distant end of an EDMAC link!

Types of pass-through commands:

- To a local modem;
- To a modem at the distant end (EDMAC);
- To a local BUC or transceiver connected to a local modem;
- To a distant end BUC or transceiver through the distant end modem.

C.5 Packet Structure

| Controller-to-Target | | | | | | |
|---|----------------|---|------------------|--|--------------------|---|
| Start of Packet | Target Address | Address Delimiter | Instruction Code | Code Qualifier | Optional Arguments | End of Packet |
| < ASCII code 60 (1 character) | | / ASCII code 47 (1 character) | | = or ? ASCII codes 61 or 63 (1 character) | | Carriage Return ASCII code 13 (1 character) |

| Target-to-Controller | | | | | | |
|---|----------------|---|------------------|---|-----------------------------|---|
| Start of Packet | Target Address | Address Delimiter | Instruction Code | Code Qualifier | Optional Arguments | End of Packet |
| > ASCII code 62 (1 character) | | / ASCII code 47 (1 character) | | =, ?, !, or * ASCII codes 61,63,33 or 42 (1 character) | (From 0 to n characters) | Carriage Return, Line Feed ASCII codes 13,10 (2 characters) |

C.5.1 Start of Packet

Controller-to-Target: This is the character '<' (ASCII code 60)

Target-to-Controller: This is the character '>' (ASCII code 62)

Because this is used to provide a reliable indication of the start of packet, these two characters may not appear anywhere else within the body of the message.

C.5.2 Target Address

While up to 9,999 devices can be uniquely addressed, connection to the CRS-311 imposes some basic limitations.

In **RS-232** applications, the Switch address is fixed at 0000.

In **RS-485** applications, the Switch may be set to an address of 1000, 3000, 5000 or 7000. This allows up to four Switches to be connected on the same bus.

Remote commands and queries that can be sent to the modems via the Switch depend upon the modem protocol and the installed options. Please consult the appropriate modem manual for further information. An external M&C application can monitor the modems, transparently through the Switch, using *virtual* addressing:

- 0100 for the TM, and
- 1100 for the RM, which are **added to the address of the Switch**.

Note that regardless of the Switch remote communications being configured for either RS-232 or RS-485 mode, the *internal* link between the Switch and the modems is always fixed at RS-232, 9600 baud, 8-N-1, address 0.

The Controller sends a packet with the address of a Target - the destination of the packet. When the Target responds, the address used is the same address, to indicate to the Controller the source of the packet. The Controller does not have its own address.

C.6 Instruction Code

This is a three-character alphabetic sequence that identifies the subject of the message. Wherever possible, the instruction codes have been chosen to have some significance. For example,

BKH is for **BacKup Holdoff** time,

SID is for **Switch ID**, etc.

This aids in the readability of the message if seen in its raw ASCII form. Only upper case alphabetic characters may be used (A-Z, ASCII codes 65 - 90).

C.6.1 Instruction Code Qualifier

This single character further qualifies the preceding instruction code. Code Qualifiers obey the following rules:

1. From **Controller-to-Target**, the only permitted values are:

=
(ASCII code 61)

The **=** code is used as the **assignment** operator, and is used to indicate that the parameter defined by the preceding byte should be set to the value of the argument(s) that follow it. For example, BKH=12 would mean 'set the **BacKup Holdoff** time to 12 seconds.'

?
(ASCII code 63)

The **?** code is used as the **query** operator, and is used to indicate that the target should return the current value of the parameter defined by the preceding byte. For example, BKH? means 'what is the current value of **BacKup Holdoff** time?'

2. From **Target-to-Controller**, the only permitted values are:

| | |
|------------------------------|---|
| = (ASCII code 61) | The = code is used in two ways: First, if the controller has sent a query code to a target (for example: BKH? meaning 'what is the BacKup Holdoff time?'), the target would respond with BKH=xx , where xx represents the time in question. Second, if the controller sends an instruction to set a parameter to a particular value, then, providing the value sent in the argument is valid, the target will acknowledge the message by replying with BKH= (with no message arguments). |
| ? (ASCII code 63) | The ? code is only used as follows: If the controller sends an instruction to set a parameter to a particular value, then, if the value sent in the argument is not valid, the target will acknowledge the message by replying (for example) with BKH? (without message arguments). This indicates that there was an error in the argument of the message sent by the controller. |
| ! (ASCII code 33) | The ! code is only used as follows: If the controller sends an instruction code that the target does not recognize, the target will acknowledge the message by echoing the invalid instruction, followed by the ! character with. Example: XYZ! |
| * (ASCII code 42) | The * code is only used as follows: If the controller sends an instruction to set a parameter to a particular value, then, if the value sent in the argument is valid, but the modem will not permit that particular parameter to be changed at that time, the target will acknowledge the message by replying (for example) with BKH* (with no message arguments). |
| # (ASCII code 35) | The # code is only used as follows: If the controller sends a correctly formatted command, BUT the modem is not in remote mode, it will not allow reconfiguration, and will respond with, for example, BKH# (with no message arguments). |
| ~ (ASCII Code 126) | The ~ code is only used as follows: If a message was sent via the Switch to an attached modem or ODU, the message was transmitted transparently through the Switch. In the event of the other device not responding, the Switch would generate a response e.g. >0100/MGC~ indicating that it had finished waiting for a response and was now ready for further COMs. |

C.6.2 Optional Message Arguments

Arguments are not required for all messages. Arguments are ASCII codes for the characters 0 to 9 (ASCII codes 48 to 57), A to Z (ASCII codes 65 to 90), period (ASCII code 46), and comma (ASCII code 44).

C.6.3 End of Packet

Controller-to-Target: This is the 'Carriage Return' character (ASCII code 13)

Target-to-Controller: This is the two-character sequence 'Carriage Return', 'Line Feed'. (ASCII code 13, and code 10).

Both indicate the valid termination of a packet.

C.7 Remote Commands and Queries

Where Column 'C' = Command; Column 'Q' = Query; Columns marked (X) indicate Command only, Query only, or Command/Query for Instruction Code.

| Instr Code | C | Q | Page |
|------------|---|---|------|
| AAM | X | X | C-10 |
| ACT | | X | C-8 |
| AMQ | | X | C-9 |
| BBU | X | X | C-9 |
| BKH | X | X | C-9 |
| CAE | X | | C-12 |
| CLD | X | | C-11 |
| CST | X | X | C-11 |
| DAY | X | X | C-11 |
| EID | | X | C-7 |
| FLT | | X | C-13 |
| IMS | X | X | C-8 |
| LRS | X | X | C-7 |

| Instr Code | C | Q | Page |
|------------|---|---|------|
| MAM | X | X | C-10 |
| MOD | | X | C-7 |
| NUE | | X | C-11 |
| OPM | X | X | C-9 |
| RNE | | X | C-12 |
| RSH | X | X | C-9 |
| SAM | X | X | C-10 |
| SGC | X | X | C-10 |
| SID | X | X | C-7 |
| SNO | | X | C-7 |
| SWR | | X | C-7 |
| TIM | X | X | C-11 |
| XMI | | X | C-8 |

| Parameter Type | Command (Code and qualifier) | Arguments for Command or Response to Query | Description of Arguments (Note that all arguments are ASCII numeric codes: i.e., ASCII codes between 48 and 57) | Response to Command (Target-to-Controller) | Query (Code and qualifier) | Response to query (Target-to-Controller) |
|----------------------|------------------------------|--|---|--|----------------------------|--|
| Local/ Remote Status | LRS= | 1 byte, value of 0 or 1 | Command or Query. x indicates the local/remote status of the Switch: 0 = local 1 = remote | LRS= (message OK) LRS? (received OK, but invalid arguments found) | LRS? | LRS=x (see description of arguments) |
| Serial Number | N/A | 9 bytes, numerical | Query only. Unit returns its 9-digit serial number. Example: SNO=176512523 | N/A | SNO? | SNO=xxxxxxx (see description of arguments) |
| Software Revision | N/A | 5 bytes, numerical | Query only. Unit returns the value of internal software revision installed in the unit, in the form x.x.x Example: SWR=1.0.1 (indicating Version 1.0.1) | N/A | SWR? | SWR=x.x.x (see description of arguments) |
| Equipment ID | N/A | 4 bytes, alpha-numeric | Query only. Unit returns information concerning the equipment identification. S311 indicates this CRS-311 1:1 Switch unit. (S300 indicates CRS-300 1:N Switch). | N/A | EID? | EID=xxxx (see description of arguments) |
| Switch ID | SID= | 24 bytes, ASCII | Command or Query. A user-defined Switch ID, which is a fixed length of 24 characters. Valid characters include: Space () * + - , . / 0-9 and A-Z. | SID= (message OK) SID? (received OK, but invalid arguments found) SID* (message OK, but not permitted in current mode) | SID? | SID=xxxxxxxxxxxxxxxxxxxx xxxxxx (see description of arguments) |
| Modem type | N/A | 4 bytes, numeric | Query only. Unit returns information concerning the model of the Redundant Modem attached, where xxxx may be 5650 indicating the SLM-5650 modem. | N/A | MOD? | MOD=xxxx (see description of arguments) |

| Parameter Type | Command (Code and qualifier) | Arguments for Command or Response to Query | Description of Arguments (Note that all arguments are ASCII numeric codes: i.e., ASCII codes between 48 and 57) | Response to Command (Target-to-Controller) | Query (Code and qualifier) | Response to query (Target-to-Controller) |
|------------------|------------------------------|--|--|--|----------------------------|--|
| TMI/RMI types | N/A | 11 Bytes | <p>Query only. x indicates the TMI/RMI type detected in each slot position: Positions 1 through 10 are TMIs, where x may be: 0 = none present 1 = CRS-320 rev A 2 = CRS-330 3 = CRS-340 rev A 4 = CRS-340 rev B 5 = CRS-370 6 = CRS-320 rev C 7 = undefined 8 = CRS-341 9 = CRS-316 A = CRS-336 B = undefined C = CRS-315 D = CRS-325 E = CRS-335 F = CRS-345 G = CRS-365 H = CRS-365D</p> <p>Position 11 is the RMI, where y may be: 0 = none present 7 = CRS-310 D = CRS-307 E = CRS-306 F = CRS-305</p> <p>Example: XMI=20000000007</p> | N/A | XMI? | XMI=xxxxxxxxxy (see description of arguments) |
| Independent Mode | IMS= | 1 byte, value of 0 or 1 | <p>Command or Query. x indicates the normal/Independent Mode operational status of the Switch: 0 = normal operation 1 = Independent Mode enabled</p> | IMS= (message OK) IMS? (received OK, but invalid arguments found) | IMS? | IMS=x (see description of arguments) |
| Active Modems | N/A | 11 bytes, numerical | <p>Query only. The active state of the two modems – for the 311 Switch the TM is always active. (Retained for CRS-311 Switch compatibility) x indicates the Traffic Modem y indicates the Redundant Modem 0 = Modem is not active 1 = Modem active</p> | N/A | ACT? | ACT=x00000000y (see description of arguments) |

| Parameter Type | Command (Code and qualifier) | Arguments for Command or Response to Query | Description of Arguments (Note that all arguments are ASCII numeric codes: i.e., ASCII codes between 48 and 57) | Response to Command (Target-to-Controller) | Query (Code and qualifier) | Response to query (Target-to-Controller) |
|----------------------|------------------------------|--|---|--|----------------------------|---|
| Active Modem Query | N/A | 11 bytes, numerical | Query only. Indicates the state of the two Modems (Command format maintained to keep compatible with the CRS-300) x Indicates the Traffic Modem y Indicates the Redundant Modem Value: 0 = TMI/RMI not present. Modem cannot be activated. 1 = TMI/RMI present, but modem not activate. 2 = TMI/RMI present, modem active and responding. 3 = TMI/RMI present, modem active but not responding. | N/A | AMQ? | AMQ=x000000000y (see description of arguments) |
| Bridge/Backup Mode | BBU= | 3 bytes, value of 0 or 1 | Command or Query. The bridge/backup state: yy = fixed at 01 for CRS-311 0 = bridging mode, ie TM is online 1 = backing-up mode, ie RM is online. This parameter can only be changed when in Manual mode. | BBU= (message OK) BBU? (received OK, but invalid arguments) BBU* (message OK, but not permitted in current mode) | BBU? | BBU=xyy (see description of arguments) |
| Operating Mode | OPM= | 1 byte, numerical | Command or Query. x indicates the operating mode, where: 0 = manual mode 1 = auto mode | OPM= (message OK) OPM? (received OK, but invalid arguments) OPM* (message OK, but not permitted in current mode) | OPM? | OPM=x (see description of arguments) |
| Backup Holdoff Time | BKH= | 2 bytes, numerical | Command or Query. The backup holdoff time is the delay when auto mode prepares to backup a faulted modem: 01-99 = # of seconds delay after Redundant Modem has acquired Traffic Modem's configuration before online swap actually takes place. | BKH= (message OK) BKH? (received OK, but invalid arguments) BKH* (message OK, but not permitted in current mode) | BKH? | BKH=xx (see description of arguments) |
| Restore Holdoff Time | RSH= | 2 bytes, numerical | Command or Query. The restore holdoff time is the delay when auto mode prepares to return a modem (previously faulted, now good) back online due to a different Traffic Modem's failure: 01-99 = # of seconds after offline Traffic Modem lost its fault before it is put back online.. | RSH= (message OK) RSH? (received OK, but invalid arguments found) RSH* (message OK, not permitted in current mode) | RSH? | RSH=xx (see description of arguments) |

| Parameter Type | Command (Code and qualifier) | Arguments for Command or Response to Query | Description of Arguments (Note that all arguments are ASCII numeric codes: i.e., ASCII codes between 48 and 57) | Response to Command (Target-to-Controller) | Query (Code and qualifier) | Response to query (Target-to-Controller) |
|-----------------------------|------------------------------|--|---|--|----------------------------|---|
| Modem Alarm Mask | MAM= | 1 byte, numerical | Command or Query. x indicates the Modem alarm mask: 0 = no faults masked 1 = Tx faults masked 2 = Rx faults masked | MAM= (message OK) MAM? (received OK, but invalid arguments found) MAM* (message OK, but not permitted in current mode) | MAM? | MAM=x (see description of arguments) |
| Switch Alarm Mask | SAM= | 1 byte, numerical | Command or Query. x indicates the Switch alarm mask: 0 = no faults masked 1 = PSU-A faults masked 2 = PSU-B faults masked | SAM= (message OK) SAM? (received OK, but invalid arguments found) SAM* (message OK, but not permitted in current mode) | SAM? | SAM=x (see description of arguments) |
| Audio Alarm Mask | AAM= | 1 byte, numerical | Command or Query. x indicates the Audio alarm mask: 0 = no faults masked (audio enabled in response to any fault) 1 = Switch faults masked 2 = Modem faults masked 3 = All faults masked (audio never enabled) | AAM= (message OK) AAM? (received OK, but invalid arguments found) AAM* (message OK, but not permitted in current mode) | AAM? | AAM=x (see description of arguments) |
| Switch Global Configuration | SGC= | 29 bytes, numerical | Command or Query. Global configuration of the Switch, in the form: OasssssssBNNbrrMSAsssssss, where: O = Operating Mode – same as OPM (1 bytes) a = Active Modem – same as ACT for TM (1 byte) s = 9 spare bytes B = Bridge/Backup State – same as BBU (1 byte) NN = always 01 for the 311 bb = Backup Holdoff Time – same as BKH (2 byte) rr = Restore Holdoff Time – same as RSH (2 byte) M = Modem Alarm Mask – same as MAM (1 byte) S = Switch Alarm Mask – same as SAM (1 byte) A = Audio Alarm Mask – same as AAM (1 bytes) s = 8 spare bytes | SGC= (message OK) SGC? (received OK, but invalid arguments found) SGC* (message OK, but not permitted in current mode) | SGC? | SGC=OasssssssBNNbrrMSAsssssss (see description of arguments) |

| Parameter Type | Command (Code and qualifier) | Arguments for Command or Response to Query | Description of Arguments (Note that all arguments are ASCII numeric codes: i.e., ASCII codes between 48 and 57) | Response to Command (Target-to-Controller) | Query (Code and qualifier) | Response to query (Target-to-Controller) |
|--------------------------------|------------------------------|--|--|--|----------------------------|---|
| Config Store | CST= | 1 byte, numerical, 0 to 9 | Command or Query. The command forces the Switch to store its current configuration in the Configuration Memory location defined by the argument n (0 to 9). Example: CST=4 (Store current configuration in location 4) WARNING: Use with caution! If the location already contains data, it will be automatically overwritten. If in doubt, query the location first. The query returns the contents of the location. | CST= (message OK) CST? (received OK, but invalid arguments found) CST* (message OK, but not permitted in current mode) | CST?n where n is 0 to 9 | Returns the same format as the SGC, with the form: CST=xxx....xxx for a valid config, and CST* where no valid config is found |
| Config Load | CLD= | 1 byte, numerical, 0 to 9 | Command only. Forces the Switch to retrieve the Configuration Memory location defined by the argument n (0 to 9) and to re-program the Switch with that stored configuration. | CLD= (message OK) CLD? (received OK, but invalid arguments found) CLD* (message OK, but the memory location does not contain configuration info) | N/A | N/A |
| Date | DAY= | 6 bytes, numerical | Command or Query. The date, in the form ddmmyy (international date convention), where: dd = day of the month, between 01 and 31, mm = month of the year, between 01 and 12, and yy = year, between 97 and 96 (1997 to 2000, then 2000 to 2096) Example: DAY=240457 would be April 24, 2057. | DAY= (message OK) DAY? (received OK, but invalid arguments) DAY* (message OK, but not permitted in current mode) | DAY? | DAY=ddmmyy (see description of arguments) |
| Time | TIM= | 6 bytes, numerical | Command or Query. The time from midnight, in the form hhmmss, where hh = hours, between 00 and 23, mm = minutes, between 00 and 59, and ss = seconds, between 00 and 59 Example: TIM=231259 would be 23 hours, 12 minutes and 59 seconds from midnight. | TIM= (message OK) TIM? (received OK, but invalid arguments) TIM* (message OK, but not permitted in current mode) | TIM? | TIM=hhmmss (see description of arguments) |
| Number of Unread Stored Events | N/A | 2 bytes, numerical | Query only. Switch returns the number of Stored Events, which remain unread, <i>over the remote control</i> . Viewing the stored events from the front panel of the modem does not affect this value. Example: NUE=98 | N/A | NUE? | NUE=xx (see description of arguments) |

| Parameter Type | Command (Code and qualifier) | Arguments for Command or Response to Query | Description of Arguments (Note that all arguments are ASCII numeric codes: i.e., ASCII codes between 48 and 57) | Response to Command (Target-to-Controller) | Query (Code and qualifier) | Response to query (Target-to-Controller) |
|--------------------------------------|------------------------------|--|---|---|----------------------------|---|
| Clear All Stored Events | CAE= | None | Command only. Instructs the unit to clear all Stored Events. This command takes no arguments. | CAE= (message OK) CAE* (message OK, but not permitted in current mode) | N/A | N/A |
| Retrieve Next 5 unread Stored Events | N/A | 80 bytes | Query only. Switch returns the oldest 5 Stored Events, which have not yet been read over the remote control. Reply format: [cr]Sub-body[cr]Sub-body[cr]Sub-body[cr]Sub-body[cr]Sub-body[cr]Sub-body, where Sub-body=KLMddmmyyhhmmss, K is the fault/clear indicator, where F = Fault, C = Clear, I = Info L is the faulting/clearing unit, values: 1 through 9, A =TM, B=RM, C=Switch, D=Info M is the fault code, where the value depends on faulting unit: Switch codes are 1 to F, indicating the position of the fault within the FLT string. Modem codes are: 1= Unit, 2= Rx traffic, 3= Tx traffic Info codes are: 0= Power off, 1= Power on, 2= Log cleared ddmmyy is the date of the event (international format). hhmmss is the time of the event. If there are no new events, the unit replies with RNE*. If fewer than 5 events remain, the last positions are filled with zeroes. | N/A | RNE? | RNE=[cr]KLMddmmyyhhmmss[cr]KLMddmmyyhhmmss[cr]KLMddmmyyhhmmss[cr]KLMddmmyyhhmmss[cr]KLMddmmyyhhmmss (see description of arguments) |

| Parameter Type | Command (Code and qualifier) | Arguments for Command or Response to Query | Description of Arguments (Note that all arguments are ASCII numeric codes: i.e., ASCII codes between 48 and 57) | Response to Command (Target-to-Controller) | Query (Code and qualifier) | Response to query (Target-to-Controller) |
|-------------------|------------------------------|--|--|--|----------------------------|---|
| Faults and Status | N/A | 15 bytes, alpha-numeric | <p>Query only. Unit returns the current fault and status codes for the Switch itself, where: r = Redundant Modem: 0 = OK, 1 = RMI not present 2 = RM I/O timeout 3 = RM comms problem 4 = RM is in a test mode 5= RM is rejecting an MGC configuration string Power supply information, values 0 or 1 only. A/a = + 5V PSU-A under/over B/b = +5V PSU-B under/over C/c = +12V PSU-A under/over D/d = +12V PSU-B under/over E/e = -12V PSU-A under/over F/f = -12V PSU-B under/over m is TMI: interface mismatch: 0 = no problem, 1 indicates the TM position of a TMI interface mismatch i is modem I/O communications: 0 = no problem, 1 indicates the traffic modem is activated but is not responding.</p> | N/A | FLT? | FLT=rAaBbCcDdEeFfmi (see description of arguments) |

This page is deliberately blank.

Appendix D. INDEPENDENT MODE OPERATION

D.1 Introduction



*This feature is for use **ONLY** with the SLM-5650/5650A.*

Per customer request, an optional Independent Mode of operation in the CRS-311 switch is available for use with the SLM-5650/5650A modems. In Independent Mode, the modems each operate independently and simultaneously (dual-carrier). In this mode, the CRS-311 is used only to enable control and monitoring of both modems via a single RS-232/RS-485 control line.

D.2 Feature Description

Figure D-1 shows the CRS-311 connected in the standard way; Figure D-2 shows the CRS-311 connected in Independent Mode.

Key functionality in Independent Mode:

- a. The CRS-311 will not switch if a fault occurs. Switch configuration is “hard-wired” to primary modem:
 - i. Data switch routes data signals to/from the primary modem.
 - ii. The CRS-281x IF switch connects the Redundant Modem’s Tx IF to the User’s Tx IF.
- b. No automatic control of the Redundant or primary modem configuration:
 - i. Does NOT control the configuration of the Redundant Modem (i.e. no “mirroring” or other control of the Redundant Modem’s configuration to match the primary modem).
 - ii. Does NOT mute the RF output of primary modem under any circumstances.
- c. Supports RS-232/RS-485 remote monitor and control connectivity to both modems.

- d. The “Stored Event” LED on the CRS-311 Front Panel will flash at **twice the current rate** when Independent Mode is enabled.
- e. Independent Mode is selectable via the Front Panel menu or remote control command:
 - *To configure via the CRS-311 Front Panel menu:*
 - Select **UTIL** → **INDEP-MODE**, then press **[ENTER]**;
 - Using the **◀ ▶** buttons, select either **NORMAL-OP** or **ENABLE-INDEP**, then press **[ENTER]**.
 - *To configure via remote control command: **IMS=x**, where: $x=0$ (off), or $x=1$ (Independent Mode enabled).*




Figure D-1. Standard Connections to CRS-311




Figure D-2: CRS-311 in Independent Mode

Appendix E. CRS-311 RETROFIT FOR SLM-5650/5650A NP INTERFACE OPERATION

E.1 Introduction



This appendix describes the procedure required to upgrade any CRS-311 1:1 Redundancy Switch from traditional serial terrestrial interface operation to operation in tandem with SLM-5650/5650A Redundant and Traffic Modems equipped with the optional Network Processor (NP) Interface Module (required to handle 4-Port Ethernet data traffic).


E.1.1 Field Upgrade Kit KT-0000078 (Required for Retrofit)

| NP (Network Processor) Upgrade Redundancy Kit KT-0000078 | | |
|--|-----|--|
| CEFD P/N | QTY | Description |
| PL-0000293 | 1 | CRS-505 RMI: EIA-530, G.703, HSSI, 4-Port Ethernet |
| PL-0000294 | 1 | CRS-515 TMI: 4-Port Ethernet |
| CA-0000089 | 1 | Ribbon Cable: RMI-to-TMI |

E.1.2 Retrofit Procedure

| Step | Task | | |
|------|--|---|--|
| 1 | <p>Plug the CA-0000089 Ribbon Cable, shipped separately with the new CRS-505 RMI and CRS-515 TMI modules, into the P1 connector on the CRS-505 RMI.</p> <p>(Note: This connector is labeled and positioned identically on the CRS-515 TMI – see Step 5.)</p> |  |  |

| | | |
|----------|---|---|
| <p>2</p> | <p>Prepare the CRS-311 Switch Chassis for retrofit by loosening the thumbscrews then removing the existing RMI and TMI modules.</p> <p>(Note: The configuration shown here is for illustrative purposes only. The actual redundant/traffic modem interfaces, power modules, and controller interfaces, as originally installed, may vary.)</p> |  <p>The image shows the front panel of a CRS-311 chassis. Two modules, labeled 'Traffic Modem 4WR (TMI) CRS-308' and 'RMI', are being removed from their slots. Two large orange arrows point downwards from the modules, indicating their removal.</p> |
| <p>3</p> | <p>Thread the CA-0000089 Ribbon Cable's unconnected (loose) end through the bottom (RMI) slot opening into the CRS-311 chassis, looping the end out through the top (TMI) slot opening.</p> |  <p>The image shows the CRS-311 chassis with the ribbon cable being threaded through the bottom slot. A hand is holding the cable, and an orange arrow labeled '3' points to the cable as it enters the chassis.</p> |
| <p>4</p> | <p>Install the CRS-505 RMI into its chassis slot while pulling lightly on the unconnected (loose) end of the CA-0000089 Ribbon Cable. Engage the RMI until it is properly seated in the receptacle on the chassis backplane.</p> <p>Do not tighten the CRS-505 RMI's thumb screws at this time.</p> |  <p>The image shows a hand installing the CRS-505 RMI into the chassis slot. An orange arrow labeled '4' points to the RMI being inserted. Another orange arrow labeled '3' points to the ribbon cable being pulled through the chassis.</p> |

| | | |
|-----------------|---|---|
| <p>5</p> | <p>Connect the loose (unconnected) end of the CA-0000089 Ribbon Cable to the P1 socket on the CRS-515 TMI.</p> |  |
| <p>6</p> | <p>Install the CRS-515 TMI into its chassis slot. Engage the TMI until it is properly seated in the receptacle on the chassis' backplane.</p> | |
| <p>7</p> | <p>Securely hand-tighten the thumbscrews on both the TMI and RMI.</p> |  |

The retrofit has been completed and the CRS-311 1:1 Redundancy Switch is ready to be connected to the SLM-5650/5650A modems per **Chapter 3. CABLES and CONNECTIONS, Sect. 3.3 SLM-5650/5650A Modem Connections.**

METRIC CONVERSIONS

Units of Length

| Unit | Centimeter | Inch | Foot | Yard | Mile | Meter | Kilometer | Millimeter |
|--------------|---------------------|---------------------|---------------------|---------------------|------------------------|---------------------|-----------|------------|
| 1 centimeter | — | 0.3937 | 0.03281 | 0.01094 | 6.214×10^{-6} | 0.01 | — | — |
| 1 inch | 2.540 | — | 0.08333 | 0.2778 | 1.578×10^{-5} | 0.254 | — | 25.4 |
| 1 foot | 30.480 | 12.0 | — | 0.3333 | 1.893×10^{-4} | 0.3048 | — | — |
| 1 yard | 91.44 | 36.0 | 3.0 | — | 5.679×10^{-4} | 0.9144 | — | — |
| 1 meter | 100.0 | 39.37 | 3.281 | 1.094 | 6.214×10^{-4} | — | — | — |
| 1 mile | 1.609×10^5 | 6.336×10^4 | 5.280×10^3 | 1.760×10^3 | — | 1.609×10^3 | 1.609 | — |
| 1 mm | — | 0.03937 | — | — | — | — | — | — |
| 1 kilometer | — | — | — | — | 0.621 | — | — | — |

Temperature Conversions

| Unit | ° Fahrenheit | ° Centigrade |
|--------------------|--------------|-----------------------|
| 32° Fahrenheit | — | 0 (water freezes) |
| 212° Fahrenheit | — | 100 (water boils) |
| -459.6° Fahrenheit | — | 273.1 (absolute 0) |

| Formulas |
|------------------------|
| $C = (F - 32) * 0.555$ |
| $F = (C * 1.8) + 32$ |

Units of Weight

| Unit | Gram | Ounce Avoirdupois | Ounce Troy | Pound Avoirdupois | Pound Troy | Kilogram |
|---------------|-------------------|-------------------|------------|-------------------|------------|----------|
| 1 gram | — | 0.03527 | 0.03215 | 0.002205 | 0.002679 | 0.001 |
| 1 oz. avoird. | 28.35 | — | 0.9115 | 0.0625 | 0.07595 | 0.02835 |
| 1 oz. troy | 31.10 | 1.097 | — | 0.06857 | 0.08333 | 0.03110 |
| 1 lb. avoird. | 453.6 | 16.0 | 14.58 | — | 1.215 | 0.4536 |
| 1 lb. Troy | 373.2 | 13.17 | 12.0 | 0.8229 | — | 0.3732 |
| 1 kilogram | 1.0×10^3 | 35.27 | 32.15 | 2.205 | 2.679 | — |



2114 WEST 7TH STREET TEMPE ARIZONA 85281 USA

480 • 333 • 2200 PHONE

480 • 333 • 2161 FAX